




RD6000
Cellular Phone



RD6000




RD6000

Contents

- ⚠ WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as a bathroom, swimming area, etc.**
- ⚠ Caution: Use only LG-approved batteries and travel chargers to avoid the damage to the phone. Using other batteries or chargers voids your warranty and may cause an explosion.**
- ⚠ Caution: Do not use batteries and travel chargers for other than the intended purposes.**
- ⚠ Never store your phone in temperatures less than -20° C or greater than 50° C, such as outside during a snowstorm or in your car on a hot day. Exposure to excessive cold or heat may result in phone malfunction, damage and/or failure.**
- ⚠ Use caution when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby inadequately shielded electronic equipment. Consult manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone. Turn off your phone in a medical facility or at a gas station.**

IMPORTANT! Please read the TIA safety information in chapter 5 before using your phone.

Introduction	7
Important Information	7
Check Accessories	7
Bodily Contact During Operation	8
Vehicle-Mounted External Antenna	9
FCC Part 15 Class B Compliance	9
Battery Safety	9
Battery Disposal	10
Charger and Adapter Safety	10
Getting Started	11
Phone Components	11
Phone Overview	12
Using the Battery Pack	14
Installing the Battery	14
Removing the Battery	14
Battery Charge Level	15
Battery Information and Care	16
Screen Icons	17
Phone Menu Reference	18
Accessories	20
Travel Charger	20
Battery	20
Cigarette Lighter Charger	20
Hands-Free Car Kit (Portable)	21
Data Cable	21
Headset	21
Safety Information	22
Explosion, Shock, and Fire Hazards	22
General Warnings and Cautions	23
Basic Functions	25
Turning the Phone On and Off	25
Turning the Phone On	25
Turning the Phone Off	25
Making a Call	26
Correcting Dialling Mistakes	26
Receiving Calls	27




RD6000

Using Vibrate, Silence All, and Lock Mode	27
Vibrate Mode (Quick)	27
Silence All Mode (Quick)	28
Lock Mode (Quick)	28
Call Waiting	28
Mute	29
Redialling Calls	29
Adjusting the Volume	29
Power Save Mode	29
Signal Strength	30
Speed Dialling	30
Caller ID	30
Additional Functions	31
Entering information using T9 Text Input	31
Input Mode	31
Key Functions	32
Changing Letter Case	33
Example: Using T9 Text Input	33
Using the NEXT Key	34
Adding Words to the T9 Database	34
Examples Using Abc (Multi-tap) Text Input	35
Phone Book Features	35
Personal Phone Book Memory	35
Saving Numbers in Your Personal Phone Book	35
Retrieving Numbers	36
Retrieving by Name Search	36
Menu Features	37
General Guidelines	37
Camera	38
Take Pix	38
Gallery	39
Send Pix Msg	40
Pix Inbox	40
Pix Outbox	41
Pix Draft	42
Pix Settings	43
Erase All	44

RD6000

Contacts45
List Contacts45
New Number45
New E-mail46
Groups46
Speed Dials47
Voice Dials47
My Contact Info48
Call History48
Dialed Calls48
Received Calls49
Missed Calls49
Erase Calls50
Call Duration50
1x Packet Counter50
Messages51
Message Menu52
New Message Alert52
Voice Mail53
New Message53
Inbox56
Out of Memory Warning57
Outbox58
Message Status Reference60
Draft60
Msg Settings61
Erase All63
R World64
R World64
Display65
Service Area65
Banner65
Backlight65
Screens67
Menu Style67
Clocks67
Theme Colour68



RD6000

Fonts	68
Power Saver	69
Status Light	69
My Media	69
Graphics	69
Music	70
Tools	71
Scheduler	71
Alarm Clock	72
Voice Memo	72
My Menu	73
Notepad	73
Easy Tip Calculation	73
Calculator	74
World Clock	74
Settings	75
Sounds	75
Security	78
Call Setup	81
1x Data	84
Voice Services	86
Phone Info	88
Safety Guidelines	89
TIA Safety Information	89
Exposure to Radio Frequency Signal	89
FDA Consumer Update	93
Consumer Information on SAR	103
Service Center List	105

RD6000

Introduction

Congratulations on your purchase of the advanced and compact RD6000 cellular phone, designed to operate with the latest digital mobile communication technology, Code Division Multiple Access (CDMA). Along with the many advanced features of the CDMA system such as greatly enhanced voice clarity this phone offers:


- Large, easy-to-read, 7-line backlight LCD with status icons.
- Paging, messaging, voice mail, and caller ID.
- 19-key keypad.
- Long battery stand-by and talk time.
- Menu-driven interface with prompts for easy operation and configuration.
- Any key answer, auto answer, auto retry, one-touch and speed dialling with 99 memory locations.

Important Information

This user's manual provides important information on the use and operation of your phone. Please read all the information carefully prior to using the phone for the best performance and to prevent any damage to or misuse of the phone. Any unapproved changes or modifications void your warranty.

Check Accessories

Your mobile phone comes with a travel charger, hand strap headset and two rechargeable batteries. Please verify that these accessories are included.



RD6000



FCC RF Exposure Information

WARNING! Read this information before operating the phone.

In August 1996, the Federal Communications (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.



CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin a minor burn may result. Contact your local dealer for a replacement of antenna.

Bodily Contact During Operation

This device was tested for typical use with the back of the phone kept 3/4 inches (2 cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 3/4 inches (2 cm) must be maintained between the user's body and the back of the phone, including the antenna

RD6000

whether extended or retracted. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Avoid the use of accessories that cannot maintain 3/4 inches (2 cm) distance between the user's body and the back of the phone and have not been tested for compliance with FCC RF exposure limits.

Vehicle-Mounted External Antenna

(Optional, if available.)


A minimum distance of 8 inches (20 cm) must be maintained between the user / bystander and the vehicle-mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov.

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that causes undesired operation.

Battery Safety

- Do not disassemble.
- Do not short-circuit.
- Do not expose to high temperatures :60 °C (140 °F)
- Do not incinerate.



RD6000

RD6000

Battery Disposal

- Please dispose of your battery properly.
- Do not dispose of your battery in fire or with hazardous or flammable materials.

Charger and Adaptor Safety

- Using the wrong battery charger could damage your phone and void your warranty.
- The charger and adaptor are intended for indoor use only.
- Do not expose the battery charger or adaptor to direct sunlight or use it in places with high humidity, such as a bathroom.




1 Getting Started

Phone Components

The following shows key components of your mobile phone.





RD6000

RD6000

Phone Overview

1. Earpiece

2. Flip Design Open the case to answer an incoming call and close to end the call.

3. Message Key Use to retrieve or send voice and text messages.

4. CALL Use to place or answer calls.

5. Side Keys Use to adjust the ringer volume in standby mode and the earpiece volume during a call.

6. Headset Jack

7. Vibrate Mode

Use to set the Vibrate Mode by pressing and holding the  key for about 3 seconds while in standby mode.

NOTE: The vibrate mode you select remains in effect even when you turn the phone off and back on.

Silence All Mode Key

Set the Silence All Mode by pressing and holding the  key for about 3 seconds while in Vibrate Mode.

When flip of the phone is closed, press and hold Voice Dial key to change vibrate mode, silence all and normal mode in sequence.

In silence all mode, press and hold  key to be entered into normal mode.

8. LCD Screen Displays messages and indicator icons.

9. Soft Keys

Left Soft Key 

Use to display the function setting menu.

Right Soft Key 

Use to select an action within a menu.

10. Lamp The red light illuminates when you turn the power on and when you have an incoming call or message.

11. Navigation Key Use for quick access to phone functions:

 My Menu (Default is Scheduler).

 Text and Voice Mail notification messages.

 R World.

 Ringers.

12. END/PWR Use to turn the power on/off and to end a call. Using this key, you can return to the main menu display screen.


13. CLR Press to delete a single space or character. Press and hold to delete entire words. Press this key once in a menu to go back one level.

14. Alphanumeric Keypad Use to enter numbers and characters and choose menu items.

15. Lock Mode Key Use in standby mode to set the lock function by pressing and holding the  key for about 3 seconds.

16. Microphone

17. Camera Key  Use to take pictures.



RD6000

Using the Battery Pack

Note: It is important to charge the battery fully before the initial use of the phone.

The phone comes with a rechargeable battery. Keep the battery charged while not in use in order to maximize talk and standby time when using the phone.

Installing the Battery

To install the battery, insert the bottom of the battery into the opening on the back of the phone. Then push the battery down until the latch clicks.

Removing the Battery

Turn the power off. Lift the release latch to detach the battery.



14

RD6000

GETTING STARTED

Battery Charge Level

The battery charge level is shown at the top right of the LCD screen.




Fully Charged

Fully Discharged

When the battery charge level becomes low, the low battery sensor alerts you in three ways: sounding an audible tone, blinking the battery icon, and displaying **LOW BATTERY WARNING!** If the battery charge level becomes exceedingly low, the phone automatically switches off and any function in progress is not saved.

15



RD6000


RD6000

Battery Information and Care

1. Never use an unapproved battery since this could damage the phone and / or battery and could cause the battery to explode.
2. The battery does not need to be fully discharged before recharging.
3. Use only LG approved chargers specific to your phone model since they are designed to maximize battery life.
4. Do not disassemble or short-circuit the battery.
5. Keep the battery's metal contacts clean.
6. Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before replacement.
7. Recharge the battery after long periods of non-use to maximize battery life.
8. Do not expose the battery charger to direct sunlight or use it in areas of high humidity such as a bathroom.
9. Battery life will decrease if exposed to extreme hot or cold temperatures.
10. Battery life will vary due to usage patterns and environmental conditions.
11. The use of extended backlighting, and data connectivity kits affect battery life and talk/standby times.

Screen Icons

Icons	Descriptions
	Displays the strength of the signal received by the phone and current signal strength is indicated by the number of bars displayed on the screen.
	Charge level: Indicates battery charge level.
	In use. A call is in progress. * No icon indicates when the phone is in standby mode.
	No service. The phone is not receiving a system signal.
	New Text Message.
	New VoiceMail.
	New Text & Voice Message.
	New Picture Message.
	Ringer Off.
	Vibrate Mode.
	Silence All.
	Transmit/Receive(Packet data mode).
	Transmit/Receive(Dormant mode).



RD6000

RD6000

Phone Menu Reference

Press Left Soft Key Menu. Press to Scroll.

1. Camera

- 1. Take Pix
- 2. Gallery
- 3. Send Pix Msg
- 4. Pix Inbox
- 5. Pix Outbox
- 6. Pix Draft
- 7. Pix Settings
 - 1. Auto Save
 - 2. Auto Delete
 - 3. Auto Receive
 - 4. Pix Msg Alert
 - 5. Text Entry Mode
 - 6. Quick-Text
- 8. Erase All
 - 1. Inbox
 - 2. Outbox
 - 3. Draft
 - 4. All

2. Contacts

- 1. List Contacts
- 2. New Number
- 3. New E-mail
- 4. Groups
- 5. Speed Dials
- 6. Voice Dials
- 7. My Contact Info

3. Call History

- 1. Dialled Calls
- 2. Received Calls
- 3. Missed Calls
- 4. Erase Calls
 - 1. Dialled Calls
 - 2. Received Calls
 - 3. Missed Calls
 - 4. All Calls

- 5. Call Duration
 - 1. Last Call
 - 2. Received Calls
 - 3. Dialled Calls
 - 4. All Calls
- 6. 1x Packet Counter
 - 1. Received
 - 2. Transmitted
 - 3. Total

4. Messages

- 1. Voice Mail
- 2. New Message
- 3. Inbox
- 4. Outbox
- 5. Draft
- 6. Msg Settings
 - 1. Auto Save
 - 2. Auto Delete
 - 3. Msg Alerts
 - 4. Signature
 - 5. Direct View
 - 6. Entry Mode
 - 7. Edit Voice Mailbox #
 - 8. Template
- 7. Erase All
 - 1. Inbox
 - 2. Outbox
 - 3. Draft
 - 4. All

5. R World

- 1. R World
 - R World Menu
 - Settings
 - Help

6. Display

- 1. Service Area
- 2. Banner
- 3. Backlight
 - 1. Main LCD
 - 2. Front LCD
- 4. Screens
 - 1. Wallpaper
 - 2. Power On
 - 3. Power Off
- 5. Menu Style
- 6. Clocks
- 7. Theme Colour
- 8. Fonts
 - 1. Calling Digits
 - 2. Text Editor
- 9. Power Saver
- 0. Status Light

7. My Media


- 1. Graphics
- 2. Music

8. Tools

- 1. Scheduler
- 2. Alarm Clock
 - 1. Alarm 1
 - 2. Alarm 2
 - 3. Alarm 3
 - 4. Quick Alarm
- 3. Voice Memo
- 4. My Menu
- 5. Notepad
- 6. Easy Tip Calculation
- 7. Calculator
- 8. World Clock

9. Settings

- 1. Sounds
 - 1. Ringers
 - 2. Key Tone
 - 3. Volume
 - 4. Alerts
 - 1. Service Change
 - 2. Call Connect
 - 3. Back To Top
 - 5. Power On/Off Tone
- 2. Security
 - 1. Lock Phone
 - 2. Restrict
 - 3. Emergency Numbers
 - 4. Change Code
 - 5. Erase Contacts
 - 6. Reset Default
 - 7. Select Line
- 3. Call Setup
 - 1. Auto Redial
 - 2. Answer Call
 - 3. Auto-Answer
 - 4. One-Touch Dial
 - 5. Voice Privacy
 - 6. Clear Voice
- 4. 1x Data
 - 1. Data/Fax
 - 2. Select Port
 - 3. Port Speed
- 5. Voice Services
 - 1. Voice Dial Prompt
 - 2. Answering Machine
 - 3. Train Words
- 6. Phone Info
 - 1. S/W Version
 - 2. Icon Glossary
 - 3. Shortcut Help



RD6000

Accessories

There are a variety of accessories available for your mobile phone. You can select these options according to your personal communication requirements. Consult your local dealer for availability.

Travel Charger

This charger, allows you to charge the battery. It supports AC 100 - 240 Volt, 50 - 60 Hz outlets. An orange light indicates that it is charging, a green light indicates charging is complete. It takes 5 hours to charge a completely discharged battery.



Battery

Standard batteries is available for charging.



Standard

Cigarette Lighter Charger

You can operate the phone and trickle charge the phone's battery from your vehicle by using the cigarette lighter charger. It takes 5 hours to charge a completely discharged battery.



20

RD6000

GETTING STARTED

Hands-Free Car Kit (Portable)

The hands-free car kit enables you to attach the phone to the power jack in your car, providing you with hands-free operation. It can charge a completely discharged battery in 5 hours.



Data Cable

Connect your phone to your PC.




Headset

Connects to your phone, allowing hands-free operation. Includes earpiece, microphone.



21



RD6000

RD6000

Safety Information

Please read and observe the following information for the safe and proper use of your phone and to prevent any unanticipated damage. Also, keep the user's manual in an accessible place at all the times after reading it.


Explosion, Shock, and Fire Hazards

- Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- Do not use your phone in high explosive areas as the phone may generate sparks.
- Do not put your phone in a place subject to excessive dust and keep the minimum required distance between the power cord and heat sources.
- Unplug the power cord prior to cleaning your phone, and clean the power plug pin when it is dirty.
- Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or an electric shock.
- When using the power plug, ensure that it is firmly connected. If it is not, it may cause excessive heat or fire.
- Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- Do not disassemble the phone.
- Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.

- If you put your phone in a pocket or bag without covering the receptacle of the phone (power plug pin), metallic articles (such as a coin, paperclip or pen) may short-circuit the phone. Always cover the receptacle when not in use.
- Do not short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and - terminals of the battery (metal strips on the battery) upon moving. Short-circuits of the terminal may damage the battery and cause an explosion.
- Do not disassemble the battery as it may cause electric shock, short-circuit, or fire.
- Do not expose the phone to excessive vibration or a sharp impact.
- Never place your phone in a microwave oven as it will cause the battery to explode.

General Warnings and Cautions

- Store the battery in a place out of reach of children.
- Using a damaged battery or placing a battery in your mouth may cause serious injury.
- Do not place items containing magnetic components such as a credit card, phone card, bank book or a subway ticket near your phone. The magnetism of the phone may damage the data stored in the magnetic strip.
- Do not hold or let the antenna come in contact with your body during a call.
- Talking on your phone for a long period of time may reduce the call quality due to heat generated during use.



RD6000

- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference in this phone.
- Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- Use only the antenna provided or approved by LG. Unauthorized antennas, modifications or attachments may affect the quality of phone call, damage the phone or result in a violation of FCC regulations.
- Do not use the cellular phone if the antenna is damaged. If the damaged antenna gets in contact with the skin, it may cause a slight burn. Please contact LG Authorized Service Center to replace the damaged antenna.
- Do not use the cellular phone in areas where its use is prohibited. (For example: aircraft).
- Do not expose the cellular phone to high temperatures or high humidity.
- Do not immerse your cellular phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized Service Center.

24



RD6000

2 Basic Functions

Turning the Phone On and Off

Turning the Phone On

1. Install a charged battery pack or connect the phone to an external power source such as a cigarette lighter adapter or car kit.
2. Press for a few seconds until the red light in the middle of the phone flashes.


NOTE: Like any other radio device, avoid any unnecessary contact with the antenna while your phone is on.

Turning the Phone Off

1. Press and hold until the display turns off.

25

BASIC FUNCTIONS



RD6000

Making a Call

When you make a call, follow these simple steps:

1. Make sure the phone is turned on. If not, press .
2. Enter the phone number, with area code (if needed).
3. Press . If the phone is locked, enter the lock code.

Call Failed - indicates that the call did not go through.

Restricted - indicates outgoing calls are in restricted mode. You can only dial phone numbers saved in the *Emergency* or *Phone Book* list.

To turn off this function:

Menu ->  Settings ->  Security -> Enter Lock Code ->  Restrict -> Off -> OK

4. Press  to make the call.

If one-touch is enabled, type in the phone book speed dial number or hold the last digit until the call is made.

NOTE: The phone number and entry name appear on the display when you type in the speed dial number and hold the last digit.

Correcting Dialling Mistakes

If you make a mistake while dialling a number, press  once to erase the last digit entered or hold down  for at least two seconds to delete all digits.

RD6000

Receiving Calls

1. When the phone rings or vibrates press  to answer.
- If you press  or the side keys  while the phone is ringing, the ringing or vibration is muted for that call.
2. Press  or  twice to end the call.

Using Vibrate, Silence All, and Lock Mode

Vibrate Mode (Quick)

Use the Vibrate Mode in public places.


1. When in the Standby Mode, activate the Vibrate Mode quickly by pressing  for 3 seconds.

When the Vibrate Mode is set, the key tones are silent, and the phone is set to vibrate.

When flip of the phone is closed, press and hold Voice Dial Key to enter into vibrate mode.

NOTE: The phone remains in Vibrate Mode even if you turn it off and back on.

NOTE: To cancel Vibrate Mode, press  to switch into Silence All or Normal Mode.



RD6000

Silence All Mode (Quick)

- From the Vibrate Mode you can activate the Silence All Mode quickly by pressing for 3 seconds. When the Silence All Mode is set, the key tones are quiet and the lamp blinks instead of the phone ringing or vibrating.

NOTE: To cancel the Silence All Mode, press to switch into Vibrate Mode or Normal Mode.

Lock Mode (Quick)

Use the Lock Mode to prevent others from using your phone.

- In standby mode, to activate the Lock Mode quickly, press for 3 seconds. *Phone is now locked* is displayed.

NOTE: To cancel the Lock Mode, Press Right Soft Key **Unlock**, then enter your 4 digit password.

Call Waiting

If your cellular service offers call waiting, while a call is in progress you may hear two beeps indicating another incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call. Check with your cellular service provider for information about this function.

- Press to receive a waiting call.
- Press again to switch between calls.

RD6000

Mute

The mute function prevents the other party from hearing your voice, but allows you to hear the other party.

- Press Left Soft Key **Mute**, during a call.
- To cancel Mute, press Left Soft Key again.

Redialling Calls

- Press to redial the last number in your call history. The last 30 numbers are stored in the call history list and you can also select one of these to redial.

Adjusting the Volume


Use the side keys to adjust the earpiece, ringer, and volumes. The upper key is used to increase the volume and the lower key is used to decrease the volume.

- You may adjust the earpiece volume during a call.
- The ringer volume can be adjusted through the menu.
- The key beep volume is adjusted through the menu.

Power Save Mode

When the phone is in an area without service for 15 minutes, it stops searching for service and enters into Power Save Mode. When your phone activates this feature, *Power Save* is displayed on the screen.

The phone automatically checks for service periodically or you can check manually by pressing any key.



RD6000

RD6000

Signal Strength

Call quality depends on the signal strength in your area. The signal strength is indicated on the screen as the number of bars next to the signal strength icon: The more bars, the better the signal strength. If the signal quality is poor, move to an open area. If you are in a building, the reception may be better near a window..

Speed Dialling

Speed dialling is a convenient feature that allows you to make phone calls quickly and easily (Number 1 is always for Voicemail).

1. Enter a speed dial number from 2 to 99.
2. Press .

OR

Press the first digit and then press and hold the key of the last digit.

Your phone recalls the phone number from your personal directory, displays it briefly and then dials it.

Caller ID

Caller ID lets you know who is calling by displaying the number of the person calling when your phone rings. If the caller's name and number are already stored in your phone book, the corresponding name appears with the number.

Check with your service provider to ensure they offer this feature.



3 Additional Functions

Entering information using T9 Text Input

You can edit the Banner, Scheduler, Short Message, Phone Book and Notepad using T9 Text Input. When editing the function of soft keys (right and left) in short message is reverse with Banner, Scheduler and Phone Book.

Input Mode

T9 Text Input provides five modes for entering text, numbers, special characters, and punctuation.

T9Word (T9) Mode

Type text using one keystroke per letter. The phone translates keystrokes into common words by using the letters on each key and a compressed database.

Abc (Multi-tap) Mode


Use Abc mode to add words to the T9 database.

123 (Numbers) Mode

Type numbers using one keystroke per number. To change to 123 mode in a text entry field, press Right Soft Key and select 123 mode.

Symbols Mode

Insert special characters or punctuation. You may use any of the 31 special characters. When the cursor is located where you want the special character, switch to Symbols Mode. Press the Navigation Key to cycle through and select the characters.



RD6000

Smiley Mode

When the cursor is located where you want to add a smiley, switch to the smileys mode. Press the Navigation Key to cycle through and select a smiley.

Key Functions



Right Soft Key: Press to scroll through the menus in the following order: T9Word -> Abc -> 123 -> Symbols -> Smiley.



Shift: Use to change case.



Type Text: In T9 mode, press one key per letter to enter text.



Type Numbers: In 123 mode, press once to enter numbers.



Next: In T9 mode, press to display other matching words.



Punctuation In T9 mode, press to insert punctuation in a word and complete a sentence.



Space: Press to complete a word or insert a space.



Clear: Press to delete a single space or character. Hold to delete entire words.

RD6000

Changing Letter Case

There are three options for selecting letter case:

Initial Cap (T9Word/Abc)

Only the first letter is capitalized.

Caps Lock (T9WORD/ABC)

Press to change to Caps Lock. All subsequent letters are capitalized.

Lower Case (T9word/abc)

Press again to change to lower case. All subsequent letters are in lower case.


Example: Using T9 Text Input

Typing In T9 Mode

To type the message "Call the office" follow these steps:

1. Press: Right Soft Key (or Left Soft Key) to change the case to T9Word Mode.
2. Press: .
3. Press: to complete the word and add a space.
4. Press:
.
5. The display shows: Call the office.

RD6000



RD6000

RD6000

Using the NEXT Key

After you have finished entering a word, if the word displayed is not the one you want, press **0NEXT** to display additional choices of words from the database.

For example:

1. Press: **4GH** **6MNO** **6MNO** **3DEF**.
2. The display shows the word Good.
3. Press: **0NEXT**.
4. The display gives you additional choices such as: Home, Gone, Hood, etc.

Adding Words to the T9 Database

If a word is not in the T9 database, add it by using Abc (Multi-tap) mode text entry. The word is automatically added to the T9 database when you return to T9 mode.

For example, follow these steps:

1. Press: Right Soft Key **1** (or Left Soft Key **4**) to change case to Abc (multi-tap) mode.
2. Press: **2ABC** **2ABC** **6MNO** **6MNO** **6MNO** **7PQRS**.
3. Display: Bop
4. Press: Right Soft Key **1** (or Left Soft Key **4**) to change letter case to T9 mode and then the word Bop is added to the T9 database.
5. Press: **CLR** to erase the existing word.
6. Press: **2ABC** **6MNO** **7PQRS**.
7. Display: cop
8. Press: **0NEXT** **0NEXT**.
9. Display: bop

34

Examples Using Abc (Multi-tap) Text Input

To type a new message, follow these steps:

1. Press: Right Soft Key **1** (or Left Soft Key **4**) to change case to Abc mode.
2. Press: ***OK** to change to ABC Caps Lock mode.
3. Press: **5JKL** **5JKL** **5JKL** **4GHI**.
4. Display: LG

Phone Book Features

You can store up to 500 entries in your phone book with easy access to your most frequently dialled phone numbers.


Personal Phone Book Memory

The phone has 500 personal phone book memory locations where you can store up to 5 phone numbers of up to 32 digits.

Saving Numbers in Your Personal Phone Book

1. Input the phone number that you want to save (up to 32 digits).
2. Press Left Soft Key **1 Save**, the submenu appears.
3. Select your desired label types Home, Home2, Office, Office2, Mobile, Mobile2, Pager, Fax, Fax2, None using **OK** and press **OK**.

35



RD6000

RD6000



4 Menu Features


General Guidelines

4. Use to select **New Name** or **Existing** and press .
5. Enter a name for the phone number(up to 22 characters). If you do not want to enter a name, press . A confirmation message is displayed briefly.
6. Continue saving the entry as a Speed Dial, press to select Speed Dial.
7. Enter a Speed Dial digit (e.g., 2) use the keypad and press or use to highlight the Speed Dial location and press .
8. Save the entry as a Voice Dial option by highlighting Voice Dial and press .
9. Press to select OK.

Retrieving Numbers

Retrieving by Name Search

1. Press Right Soft Key **Contacts**.
2. Enter the character(s) that you want to search for such as the first letters of the name.
3. You see a list of matches.
4. Press to see more information in that entry, or press to place the call.



RD6000

Camera (Menu 1₁)

Quick Access to Camera Feature

You can access the camera feature directly by pressing **[]** for approximately 3 seconds.

Take Pix (Menu 1₁ 1₂)

Allows you to take photos up to 20.

1. From the menu, select **Camera**.
2. Press **[1₂] Take Pix**.
3. Press Right Soft Key **[] Options** to view the list.

NOTE: Use **[]** to adjust the zoom function (x1, x2 and x4 at Low resolution, x1 and x2 at Med resolution, and only x1 at Hi resolution).

NOTE: To take a photo of yourself, use the mirror on the top front of the phone. When your image is centered in the mirror, take the photo using the volume control key.

4. Select an option with **[]**.
 - Self Timer -(5 sec / 10 sec)
 - Resolution -(Low 160x120 / Med 320x240 / Hi 640x480)
 - Brightness -(EV-2 to EV+2)
 - File Quality -(Economy / Normal / High)
 - Shutter Sound -(Shutter / Chime / No Sounds)
 - Colour Effects - (Normal / Antique / Black&White / Negative)
 - Fun Frames - (Frame 1~5 / None): Allows you to take photos with a pre-made foreground.

RD6000


- Multishot - (5 shots / 3 shots): Allows you to take multiple photos without interruption. When you put the resolution on high, you do not have 5 shots / 3 shots, you only get 2 multishots.
- 5. Take a picture by pressing **[OK]**, or you can press a Side Key **[]**.
- 6. Press Left Soft Key **[] Save** to save the photo.
- Press Right Soft Key **[] Reject** or retake the photo.

NOTE: "XX/XX" on the upper right corner of the LCD screen shows how many photos you have taken and the maximum number you can take.

Gallery (Menu 1₁ 2_{ABC})

Allows you to view photos that are stored in the phone.

1. From the menu, select **Camera**.
2. Press **[2_{ABC}] Gallery**.
3. Press Right Soft Key **[] Options** to view the list.
4. Select an option with **[]**.
 - Send
 - Set As -(Contacts / Wallpaper / Power On / Power Off)
 - Enlarge
 - Lock
 - Rename
 - Erase
 - Erase All
 - Picture Info
5. Press **[OK]**.
 - Press Left Soft Key **[] Camera** to take a photo **[OK]**.



RD6000

RD6000

Send Pix Msg (Menu 1 3)

1. From the menu, select **Camera**.
2. Press **3 Send Pix Msg** and **OK** to enter mobile number and / or E-mail.
3. Edit subject / text by selecting **OK**.
4. Select a picture file and sound file by selecting **OK**.
5. Press Right Soft Key **D Options** and select **Send**.
(Max file size: image 99 kb / text 1000 byte)

❖ Options

- | | |
|-------------|-------------|
| 1) Preview | 2) Send |
| 3) Priority | 4) Enhanced |

NOTE: Please contact your service provider for details on the MMS/Picture Messaging service.

Pix Inbox (Menu 1 4)

1. From the menu, select **Camera**.
2. Press **4 Pix Inbox** to view Photo Inbox.
(Max. 10 messages can be stored in Inbox.)

❖ Options

- | | |
|----------|---------|
| 1) Erase | 2) Lock |
|----------|---------|

3. Select a message with **OK**.

4. Press **OK** to view the message.

❖ Reply

- | | |
|------------|--------------|
| 1) Pix Msg | 2) Text Only |
|------------|--------------|

❖ Options

- | | |
|-----------------|--------------------|
| 1) Pix Msg Info | 2) Play Again |
| 3) Save Pix | 4) Save Sound |
| 5) Save Address | 6) Save Quick-Text |
| 7) Save Pix Msg | 8) Forward |
| 9) Erase | |

Photo Msg Status Reference

- : Notified Msg
- : Urgent Read Msg
- : Urgent Unread Msg
- : Read Photo Msg
- : Unread Photo Msg

Pix Outbox (Menu 1 5)

1. From the menu, select **Camera**.
2. Press **5 Pix Outbox** to view Photo Outbox.
(Max. 10 messages can be stored in Outbox.)

❖ Resend


❖ Options

- | | |
|----------|---------|
| 1) Erase | 2) Lock |
|----------|---------|

3. Select a message with **OK**.

4. Press **OK** to view the message.

❖ Send to



RD6000

RD6000

- ❖ Options
 - 1) Pix Msg Info
 - 2) Play Again
 - 3) Erase
 - 4) Save Pix
 - 5) Save Sound
 - 6) Save Address
 - 7) Save Pix Msg
 - 8) Lock

Photo Msg Status Reference

: Delivered Msg

: Failed Msg

: Sent Msg

Pix Draft (Menu **1 _{OK}** **6_{MNG}**)

Max. 5Pictures can be stored on Draft.

1. From the menu, select **Camera**.

2. Press **6_{MNG}** **Pix Draft**.

- ❖ Resume
- ❖ Options
 - 1) Erase
 - 2) Lock

3. Select a message with .

4. Press **OK** to view the message.

- ❖ Resume
- ❖ Options
 - 1) Pix Msg Info
 - 2) Play Again
 - 3) Erase
 - 4) Save Pix
 - 5) Save Sound
 - 6) Save Address
 - 7) Save Quick-Text
 - 8) Lock

Pix Settings (Menu **1 _{OK}** **7_{PORS}**)

1. From the menu, select **Camera**.

2. Press **7_{PORS}** **Pix Settings**.

3. Select an option with .

Auto Save (Menu **1 _{OK}** **7_{PORS}** **1_{ABP}**)

With this feature on, messages are automatically saved in the Pix Outbox when transmitted.

Auto Save/Prompt/Do Not Save

Auto Delete (Menu **1 _{OK}** **7_{PORS}** **2_{ABC}**)

With this feature on, old read messages are automatically deleted when you exceed storage limit.

Auto Receive (Menu **1 _{OK}** **7_{PORS}** **3_{DEF}**)


With this feature on, picture messages will automatically be received by your phone. With this feature off, you will be asked if you want to accept your new Photo Msg.

Pix Msg Alert (Menu **1 _{OK}** **7_{PORS}** **4_{GHI}**)

Allows you to select the alert type for a new picture message. Alert types are Silent, Vibrate Once, Vibrate and Sound,Custom Ring Tone, Low Beep Once, Low Beeps, Loud Beep Once and Loud Beeps.

Text Entry Mode (Menu **1 _{OK}** **7_{PORS}** **5_{IJKL}**)

Allows you to select the default input method including T9 Word, Abc, 123.



RD6000

RD6000

Quick-Text (Menu **1_{abc} **7_{PQRS}** **6_{MNO}**)**

Display, edit, and add Canned Messages.

Erase All (Menu **1_{abc} **8_{TUV}**)**

This allows you to erase all picture messages stored in your Pix Inbox, Pix Outbox or Pix Draft. You can also erase all messages stored in these folders at the same time.

1. From the menu, select **Camera**.
2. Press **8_{TUV}** **Erase All**.
 - Press **1_{abc}** **Inbox** to erase all messages stored in the Inbox
 - Press **2_{ABC}** **Outbox** to erase all messages stored in the Outbox
 - Press **3_{DEF}** **Draft** to erase all messages stored in the Draft
 - Press **4_{GHI}** **All** to erase all messages stored in the Inbox, Outbox, and Draft Items folder

NOTE: Locked messages cannot be erased.

NOTE: If the memory is full, no more messages can be received until enough memory space becomes available. The message [Pix Msg Inbox] is full is displayed and new messages are not accepted.

44

Contacts (Menu **2_{ABC})****List Contacts (Menu **2_{ABC}** **1_{abc}**)**

Allows you to view the list of entries in Contacts.


1. Press Left Soft Key **¶ Menu**.
2. Press **2_{ABC}** **Contacts**.
3. Press **1_{abc}** **List Contacts**.
4. Press Right Soft Key **» Options**, and then press **OK**.
 - Find Name / Find Number / Find Speed Dial / Find Group / Find E-mail / Send Message / Erase
5. You may register a new phone number by pressing Left Soft Key **¶ New**.
 - New Number / New E-mail

New Number (Menu **2_{ABC} **2_{ABC}**)**

Allows you to add a new number into Contacts.

1. Press Left Soft Key **¶ Menu**.
2. Press **2_{ABC}** **Contacts**.
3. Press **2_{ABC}** **New Number**.
4. Enter the number and press **OK**.
5. Select the label you want and press **OK**.
6. Enter the Name and press **OK**.
7. Select either Speed Dial or Voice Dial and press **OK**.

45



RD6000

RD6000

New E-mail (Menu **2_{ABC} 3_{DEF}**)

You can save E-mail addresses.

1. Press Left Soft Key **Menu**.
2. Press **2_{ABC} Contacts**.
3. Press **3_{DEF} New E-mail**.
4. Enter the E-mail address and press .
5. Enter the Name and press .

Groups (Menu **2_{ABC} 4_{GHI}**)

Allows you to enter a new group, change the name of a group, or delete a whole group.

1. Press Left Soft Key **Menu**.
2. Press **2_{ABC} Contacts**.
3. Press **4_{GHI} Groups**.
4. Highlight the Group you wish to view and then press .
5. To add a new group to the list, press Left Soft Key **Add**; to delete a group or to change the name, press Right Soft Key **Options**.

- **Edit title**
- **Erase group**

Speed Dials (Menu **2_{ABC} 5_{IJKL}**)

Allows you to set the speed dial keys for the designated phone numbers.

1. Press Left Soft Key **Menu**.
2. Press **2_{ABC} Contacts**.
3. Press **5_{IJKL} Speed Dials**.
4. **Next empty / Remove / Remove all** pop up is displayed by pressing Right Soft Key .
5. Either select the number you wish to speed dial, or enter the number you want and press .


Voice Dials (Menu **2_{ABC} 6_{MNO}**)

Allows you to view the list of numbers that have been programmed with voice dialling or add a voice dial tag to a number in Contacts.

1. Press Left Soft Key **Menu**.
2. Press **2_{ABC} Contacts**.
3. Press **6_{MNO} Voice Dials**.
4. Press Left Soft Key **New**.

How to Use: Record the voice dial tags by following the phone's prompts. When recording the voice tag, place the phone in a normal phone use position with the speaker by your ear and the microphone near your mouth.

NOTE: Recordings should be made in a quiet place using a clear voice. Hands-free car kits or headsets should be avoided when recording.



RD6000

RD6000

My Contact Info (Menu **2_{ABC} 7_{PQRS}**)

Allows you to enter your own virtual business card and save my personal information.

1. Press Left Soft Key **Menu**.
2. Press **2_{ABC} Contacts**.
3. Press **7_{PQRS} My Contact Info**.
4. Select the feature you want to edit by highlighting it and pressing **OK**.

Call History (Menu **3_{DEF}**)

Allows you to view a list of the last phone numbers or Phone Book entries for calls you placed, accepted, or missed. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Total call history numbers: 90(Dialed Calls:30 / Received Calls:30 / Missed Call:30)

NOTE: To view a quick list of all your Call History, press from the main menu.

- indicates a Dialed Call.
- indicates a Received Call.
- indicates a Missed Call.

Dialed Calls (Menu **3_{DEF} 1_{abc}**)

Allows you to view the list of outgoing calls; up to 30 numbers and entries.

1. Press Left Soft Key **Menu**.

2. Press **3_{DEF} Call History**.

3. Press **1_{abc} Dialed Calls**.

4. Highlight the entry you wish to view and press **OK** or you may place a call by pressing .

- Press Right Soft Key **Options** to select : Save / Send Msg. / Prepend / Erase / Erase All

Received Calls (Menu **3_{DEF} 2_{ABC}**)

Allows you to view the list of incoming calls; up to 30 numbers and entries.

1. Press Left Soft Key **Menu**.

2. Press **3_{DEF} Call History**.

3. Press **2_{ABC} Received Calls**.

4. Highlight the entry you wish to view and press **OK**, or you may place a call by pressing .

- Press Right Soft Key **Options** to select : Save / Send Msg. / Prepend / Erase / Erase All

Missed Calls (Menu **3_{DEF} 3_{DEF}**)


Allows you to view the list of missed calls; up to 30 numbers and entries.

1. Press Left Soft Key **Menu**.

2. Press **3_{DEF} Call History**.

3. Press **3_{DEF} Missed Calls**.

4. Highlight the entry you wish to view and press **OK**, or you may place a call by pressing .



RD6000

- Press Right Soft Key **Options** to select :
Save / Send Msg. / Prepend / Erase / Erase All

Erase Calls (Menu 3_{DEF} 4_{GHI})

Allows you to erase the call history list.

1. Press Left Soft Key **Menu**.
2. Press **3_{DEF} Call History**.
3. Press **4_{GHI} Erase Calls**.
4. Select the list of calls you wish to erase and press **OK**.
 - Dialled Calls / Received Calls / Missed Calls / All Calls
5. Press either 1 Erase, or 2 Cancel and press **OK**.

Call Duration (Menu 3_{DEF} 5_{JKL})

Allows you to view the duration of calls.

1. Press Left Soft Key **Menu**.
2. Press **3_{DEF} Call History**.
3. Press **5_{JKL} Call Duration**.
4. Select from Last Call / Received Calls / Dialled Calls / All Calls, and press **OK**.

1x Packet Counter (Menu 3_{DEF} 6_{MNO})

Allows you to view the duration of calls.

1. Press Left Soft Key **Menu**.
2. Press **3_{DEF} Call History**.
3. Press **6_{MNO} 1x Packet Counter**.
4. Select from Received / Transmitted / Total and press **OK**.

RD6000

Messages (Menu 4_{GHI})

Text messages, pages, and the voicemail box become available as soon as the phone is powered on. You can access the above types of messages using the message key **✉**.


In addition, you can make a call to the reply number by pressing **Call** during a message check.

The phone can store up to 116 messages (1 voice message: 50 inbox text messages, 50 outbox text messages, 15 saved and draft text messages) with up to 160 characters per message.

Check whether your service provider provides the above features.

Character limits: The RD6000 supports up to 160 characters per message. Limits to available characters per message may exist; please check with your service provider for system capabilities.

The information that is stored in the message is determined by phone mode and service capability. You can check types of messages by pressing the message key **✉**.



RD6000

RD6000

Message Menu

- **Voice Mail:** Shows the number of messages in voice mail box.
- **New Message:** Sends a message.
- **Inbox:** Shows the list of received messages.
- **Outbox:** Shows the list of sent messages.
- **Draft:** Shows the list of saved and draft messages.
- **Msg Settings:** Adjusts Msg Setting.
- **Erase All:** Deletes all stored messages.

New Message Alert

There are four ways your phone alerts you to new messages.

1. The phone displays the message on the screen.
2. One of four ring types is heard if selected.
3. The red light blinks.
4. The message icon is displayed on the display screen . In the case of an urgent message, the icon will flash and displays **Urgent message**.

NOTE: If you receive the same message twice, your phone deletes the older one and the new one is stored as a Duplicate.

52

Voice Mail (Menu **4_{GHI} 1_{AB}**)

Allows you to view new voice messages recorded in the voice mailbox. Once you exceed the storage limit, the old messages are overwritten. When you have a new voice message, your phone alerts you.

NOTE: Only one voice message can be stored in mailbox.

Checking your Voice Mail box

1. Press Left Soft Key **Menu**.
2. Press **4_{GHI} Messages**.
3. Select **1_{AB} Voice Mail**.

- To delete information press Left Soft Key **Clear** and then select Clear Count.

New Message (Menu **4_{GHI} 2_{ABC}**)


You can send text messages and pages transmissions.

Text messages: Transmits text (with or without numbers).

Page messages: Transmits only numbers without text.

To send a message, enter an SMS phone number to Address 1.

53



RD6000

RD6000

Menu

Address 1: This feature allows multi-sending of up to 10 total addresses.

Select **Options** by using Right Soft Key .

There are 5 optional menus of **Send**, **Priority**, **Deferred**, **Validity**, and **Save**.

1. Press Left Soft Key **Menu**.
2. Press **Messages**.
3. Select **New Message**.
4. Enter the recipients address. The address can be typed in or taken from a Phone Book entry and Call History.
5. Enter the message. The text can be entered using the keypad or by selecting Template with Right Soft Key **Insert from Template**.

- **Template**

There are 10 "predefined" phrases included in the Canned Msg option. You can also add up to 10 of your own phrases.

6. Select **Options** using Right Soft Key after entering the number of other party and the content with the Navigation Key. Select the item with .

Send Allows you to send the message.

Priority Allows you to give priority to message. Normal or Urgent.

Deferred Allows you to delay sending the message until the programmed

time frame. Deferred time frames are as follows:
Immediate, After 30 minutes,
After 1 hour, After 2 hours,
After 12 hours, After 1 day,
After 2 days, and After 3 days.

Validity


Indicates the validity of message delivery to the Short Message Center (SMC) without being transmitted to the destination address for certain periods of time. Those messages will be deleted within the programmed time frame. Validity time frames are as follows: Default, 30 minutes, 1 hour, 2 hours, 12 hours, 1 day, 2 days, and 3 days.

Save

Save the message into the Draft folder.

If you select Send, it notifies you that the message was sent successfully.

NOTE: If you send an SMS message to a phone without SMS, you will still be notified that the message was sent, however the message will not be received.



RD6000

Inbox (Menu 4_{GH} 3_{DEF})

Received text messages and page messages lists may be searched and the contents may be viewed. Received messages are displayed from newest to oldest.

To view the list of the received messages:

1. Press Left Soft Key **Menu**.
2. Press 4_{GH} **Messages**.
3. Select 3_{DEF} **Inbox**.
4. **Erase / Lock** pop up is displayed by pressing Right Soft Key .

Reply w Copy Replies to the SMS with the original message attached.

Forward Forwards a received message to others. After recipients are entered, the message can be forwarded.

Erase Deletes the selected message from the Inbox.

Save Address Stores the reply number, e-mail address, and numbers in user data included in the received message into your Phone Book. You can store the received number information in the corresponding number list in the Phone Book.

For an e-mail address, select the option New Entry and Old Entry. The new e-mail address may overwrite an old address entry. For new entries, an e-mail address may be stored with the new memory number.

NOTE: A phone number having minimum 10 digits can only be allowed to store.

Save to Template Save the message into the Template list.


Save Message Save Inbox message into the Draft Folder.

Lock/Unlock Locks or unlocks the selected message. Locked messages cannot be deleted by the Erase Inbox, Erase Outbox and Erase All functions.

Out of Memory Warning

If the memory is full, no more messages can be received until enough memory space becomes available. The message **Inbox Full Please erase message** is displayed and new messages are not accepted.

RD6000



RD6000

RD6000

Outbox (Menu)

Up to 50 sent messages can be stored in the Outbox. Users may view lists and contents of sent messages in this menu and may also verify whether the transmission was successful or not.

1. Press Left Soft Key .
2. Press **Messages**.
3. Select **Outbox**.
4. **Erase / Lock** pop up is displayed by pressing Right Soft Key .

Resend Allows you to retransmit the selected message.

Erase Use to delete a selected message in the Outbox.

Save Address Stores the reply number, e-mail address, and numbers in user data included in the received message into your Phone Book. You can store the received number information in the corresponding number list in the Phone Book. For an e-mail address, select the option New Entry and Old Entry. The new e-mail address may overwrite an old address entry.

For new entries, an e-mail address may be stored with the new memory number.

NOTE: A phone number having minimum 10 digits can only be allowed to store.


Save to Template Save the message into the Template list.

Save Message Save outbox message into the Draft folder.

Lock / Unlock Lock a message so that it is not erased if the Erase Inbox or Erase All feature is used.

Cancel Cancels the transmitted message.

Status Code Checks the sent message information (Err Class/Cause Code).



RD6000

RD6000

Message Status Reference

Icons		Descriptions
	Sent	Messages saved in Short Message Center (SMC) have been transmitted.
	Fail	Indicates a failed message transmission.
	Delivery	Message has been delivered.
	Cancel	After transmission to message center has occurred, messages that have not been delivered may be canceled by transmitting cancel message.
	Multi-sending	Indicates more than one designated recipient.
	Pending	Transmission is unavailable in a no service area. Messages are pending transmission. Pending messages are transmitted automatically when digital mode becomes available.

Draft (Menu 4_{GH} 5_{JKL})

Displays all the saved and draft messages.

1. Press Left Soft Key **Menu**.
2. Press **4_{GH} Messages**.
3. Select **5_{JKL} Draft**.
4. **Erase / Lock** pop up is displayed by pressing Right Soft Key .

Send to Allows you to retransmit the selected message.

Erase Use to delete a selected message in the Draft.

Save Address

Stores the reply number, e-mail address, and numbers in user data included in the received message into your Phone Book. You can store the received number information in the corresponding number list in the Phone Book. For an e-mail address, select the option New Entry and Old Entry. The new e-mail address may overwrite an old address entry. For new entries, an e-mail address may be stored with the new memory number.

Save to Template

Save the message into the Template list.

Lock / Unlock


Lock a message so that it is not erased if the Erase Draft or Erase All feature is used.

Draft Message: Displays the list of messages which have failed to write a message.

Saved Message: Displays the list of saved messages in Inbox / Outbox.

Msg Settings (Menu 4_{GH} 6_{MNO})

1. Press Left Soft Key **Menu**.
2. Press **4_{GH} Messages**.
3. Select **6_{MNO} Msg Settings**.



RD6000

Auto Delete, Msg Alerts and Direct View may be configured for receiving new messages.
The phone alerts you in 3 ways when you receive a new message:

- By displaying a message on the screen.
- By sounding a beep or vibrating.
- By blinking.

Auto Save (Menu 4_{GHI} 6_{MNO} 1_{ABC})

With this feature on, messages are automatically saved in the Outbox when transmitted.

- Auto Save / Prompt / Do Not Save

Auto Delete (Menu 4_{GHI} 6_{MNO} 2_{ABC})

With this feature on, old read messages are automatically deleted when you exceed the storage limit.

Msg Alerts (Menu 4_{GHI} 6_{MNO} 3_{DEF})

Allows you to select the alert type for a new message. Alert types are Voice Mail Alert, Text Msg Alert, Page Alert and 2 MIN Alert.

Signature (Menu 4_{GHI} 6_{MNO} 4_{GHI})

You may edit the signature you want to automatically send with your messages. Signature types are None and Custom.

Direct View (Menu 4_{GHI} 6_{MNO} 5_{JKL})

Allows you to directly display the content when receiving a message.

RD6000

Entry Mode (Menu 4_{GHI} 6_{MNO} 6_{MNO})

Allows you to select the default input method including T9 Word, Abc, 123.

Edit Voice Mailbox # (Menu 4_{GHI} 6_{MNO} 7_{PQRS})

Allows you to manually enter the access number for Voice Mail Service.


Template (Menu 4_{GHI} 6_{MNO} 8_{TUV})

Display, edit, and add Template.

Erase All (Menu 4_{GHI} 7_{PQRS})

This allows you to erase all text messages stored in your Inbox, Outbox or Draft Items folder. You can also erase all messages stored in these folders at the same time.

- Press 1_{ABC} Inbox to erase all messages stored in the Inbox.
- Press 2_{ABC} Outbox to erase all messages stored in the Outbox.
- Press 3_{DEF} Draft to erase all messages stored in the Draft.
- Press 4_{GHI} All to erase all messages stored in the Inbox, Outbox, and Draft Items folder.



RD6000

R World (Menu **5_{JKL}**)

R World (Menu **5_{JKL}**)

This connects you to R World Data Services like video, audio, news, games, messaging etc., provided by your service provider.

1. Press Left Soft Key **Menu**.
2. Press **5_{JKL}** **R World**.
3. R World logo will be displayed followed by R World Data Services Menu.
4. Scroll through the menu using and launch any Data Service by clicking on press .
5. To exit from Data Services any time, hold down or for a few seconds.

NOTE: Pressing the left arrow key will start R World.

NOTE: All Data Services may not be available to every subscriber. Please contact your service provider for further information.

RD6000

Display (Menu **6_{MNO}**)

Service Area (Menu **6_{MNO} 1_{QWERTY}**)

This menu displays the current SDCA / calling area the user is in.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO}** **Display**.
3. Select **1_{QWERTY}** **Service Area**.

Banner (Menu **6_{MNO} 2_{ABC}**)


Allows you to enter a string of up to 16 characters to be displayed on the LCD screen.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO}** **Display**.
3. Select **2_{ABC}** **Banner**.
4. Enter a Banner and then press .

Backlight (Menu **6_{MNO} 3_{DEF}**)

Allows you to set the duration for leaving the backlight on.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO}** **Display**.
3. Select **3_{DEF}** **Backlight**.



RD6000

Main LCD (Menu **6_{MNO} 3_{DEF} 1_{ABC}**)

Timer

- **7 seconds** turns the backlight off 7 seconds after the last key was pressed.
- **15 seconds** turns the backlight off 15 seconds after the last key was pressed.
- **30 seconds** turns the backlight off 30 seconds after the last key was pressed.
- **Always off** means that the backlight is never on.
- **On flip open** means that the backlight is always on while cellcase is open.

Brightness

Allows you to set the brightness level of the backlight.

Front LCD (Menu **6_{MNO} 3_{DEF} 2_{ABC}**)

Timer

- **5 seconds**
- **1 minute**
- **3 minutes**

Patterns

Select Incoming Calls / Missed Calls / New SMS Alert / Reminders / Standby.

Press until you find the colour you desire.

Screens (Menu **6_{MNO} 4_{GHI}**)

Allows you to choose the kind of background to be displayed on the phone.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **4_{GHI} Screens**.
4. Select Wallpaper / Power On / Power Off.
5. Select from 7 different screens and press Left Soft Key **Save**.

Menu Style (Menu **6_{MNO} 5_{JKL}**)


Allows you to choose whether you want the menu to show as a list or as icons.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **5_{JKL} Menu Style**.
4. Select *Icon* or *List* and press **OK**.

Clocks (Menu **6_{MNO} 6_{MNO}**)

Allows you to choose the kind of clock to be displayed on the LCD screen.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **6_{MNO} Clocks**.
4. Select *Normal* / *Analog* or *Digital* and press Left Soft Key **Save**.



RD6000

RD6000

Theme Colour (Menu **6_{MNO} 7_{PQRS})**

Allows you to choose the colour of the background screen.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **7_{PQRS} Theme Colour**.
4. Select an option and press .
 - Default / Green / Violet / Orange

Fon**ts (Menu **6_{MNO} 8_{TUV}**)**

Allows you to choose the size and colour of the number font.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **8_{TUV} Fonts**.

Calling Digits (Menu **6_{MNO} 8_{TUV} 1_{abc}**)

1. Select Size / Colour.
2. Press until you find the size or the colour you desire.
3. Press to save.

Text Editor (Menu **6_{MNO} 8_{TUV} 2_{ABC}**)

1. Select Size / Colour.
2. Press until you find the size or the colour you desire.
3. Press to save.

Power Saver (Menu **6_{MNO} 9_{WXYZ})**

Display and buttons are lighted for a designated length of time, allowing you to use your mobile phone in the dark with convenience.

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **9_{WXYZ} Power Saver**.
4. Select an option and press .
 - 2 min / 10 min / 30 min / Always On

Status Light (Menu **6_{MNO} 0_{NEXT})**

1. Press Left Soft Key **Menu**.
2. Press **6_{MNO} Display**.
3. Select **0_{NEXT} Status Light**.
4. Select an option and press .
 - On / Off

My Media (Menu **7_{PQRS})**


Downloads from R-World can be saved in My Media upto a maximum of:

Ringer: Brew(30) / MMS(20)

Image: Brew(30) / MMS(20)

Graphics (Menu **7_{PQRS} 1_{abc})**

Allows you to choose the background to be displayed on the phone.



RD6000

1. Press Left Soft Key **Menu**.
2. Press **My Media**.
3. Press **Graphics**.
4. **Erase / Erase All** pop up is displayed by pressing Right Soft Key .

 - Aqua / Concept / Cosmos / Desert blues / Ever green / Eye catch / Homecoming / Roar / Spring / Sunrise

5. Press Left Soft Key **Set As** to select :
 - Set As Contacts / Set As Wallpaper / Set As Power On / Set As Power Off

Music (Menu **2 ABC)**

Allows you to choose the ring tones to be heard for incoming calls.

1. Press Left Soft Key **Menu**.
2. Press **My Media**.
3. Press **Music**.
4. **Rename / Erase / Erase All** pop up is displayed by pressing Right Soft Key .

 - Calypso / Disco / Ejheboy / Pop / Trumpet

5. Press Left Soft Key **Set As** to select :
 - Set As Contacts / Set As Caller ID / Set As No Caller ID / Set As Restrict

RD6000

Tools (Menu **1)**

Scheduler (Menu **1)**

Scheduler Functions

Scheduler keeps your agenda convenient and easy to access. Simply store your appointments and your phone alerts you with a reminder of your appointment. You can also take advantage of the Alarm Clock feature.

The total number of schedulers that can be stored is 300. (30 per day.)

NOTE : Scheduler will not alert you during a call, when transmitting SMS, or when connecting up. After exiting, it will sound the reminder.


Allows you to input your schedule. If you input the time and memo, an alarm rings at the set time.

1. Press Left Soft Key **Menu**.
2. Press **Tools**.
3. Press **Scheduler**.
4. Select the date using your keypad, then press Left Soft Key **Add**.

 - Press Right Soft Key **Options** to select : Go To Today / Go To Date / Search / Erase Old / Erase All

How to use buttons

- Moves cursor to the left.
- Moves cursor to the right.
- Moves to the previous week.
- Moves to the next week.



RD6000

RD6000

Alarm Clock (Menu 8_{IUV} 2_{ABC})

1. Press Left Soft Key Menu.
2. Press 8_{IUV} Tools.
3. Select 2_{ABC} Alarm Clock.
4. Select the alarm you want to edit.
5. Set the time for alarm and press Left Soft Key Save.
 - The current time will be displayed in the upper portion of the screen.
6. You can change the alarm mode and alarm ringer type using .
7. At the alarm time, "Alarm x" will be displayed on the LCD screen and the alarm will sound.

Voice Memo (Menu 8_{IUV} 3_{DEF})

Allows you to listen to, add, and erase short verbal reminders.

1. Press Left Soft Key Menu.
2. Press 8_{IUV} Tools.
3. Select 3_{DEF} Voice Memo.
4. Press Left Soft Key New to record a new voice memo.

72

My Menu (Menu 8_{IUV} 4_{GHI})

1. Press Left Soft Key Menu.
2. Press 8_{IUV} Tools.
3. Select 4_{GHI} My Menu.

NotePad (Menu 8_{IUV} 5_{JKL})


Allows you to read, add, edit, and erase notes to yourself.

1. Press Left Soft Key Menu.
2. Press 8_{IUV} Tools.
3. Select 5_{JKL} NotePad.
4. Press Left Soft Key Add to write a new note.

Easy Tip Calculation (Menu 8_{IUV} 6_{MNO})

1. Press Left Soft Key Menu.
2. Press 8_{IUV} Tools.
3. Select 6_{MNO} Easy Tip Calculation.

73

**RD6000****Calculator (Menu 8_{TUV} 7_{PQRS})**

Calculate simple mathematical computations. (Can enter numbers up to the second decimal place.)

1. Press Left Soft Key **Menu**.
2. Press 8_{TUV} **Tools**.
3. Select 7_{PQRS} **Calculator**.

NOTE: Calculations can be made with up to 32 characters at one time (e.g. 63+78-21 would be 9 characters).

World Clock (Menu 8_{TUV} 8_{TUV})

Is useful if you need to make a call to another country and you are not sure about the time difference.

1. Press Left Soft Key **Menu**.
2. Press 8_{TUV} **Tools**.
3. Select 8_{TUV} **World Clock**.

RD6000**Settings (Menu 9_{WXYZ})****Sounds (Menu 9_{WXYZ} 1_{AB})****Ringers (Menu 9_{WXYZ} 1_{AB} 1_{AB})**

1. Press Left Soft Key **Menu**.
2. Press 9_{WXYZ} **Settings**.
3. Press 1_{AB} **Sounds** and then press 1_{AB} **Ringers**.
4. Select Caller ID / No Caller ID / Restrict.
5. Then press to save the sound.


Key Tone (Menu 9_{WXYZ} 1_{AB} 2_{ABC})

To set the Key Tone length and touch tone playback speed:

1. Press Left Soft Key **Menu**.
2. Press 9_{WXYZ} **Settings**.
3. Press 1_{AB} **Sounds** and then press 2_{ABC} **Key Tone**.
4. Set *Normal / Long* with and then press .

Normal Sends out a tone for a fixed period of time even if you keep the key pressed.

Long Sends out a continuous tone for as long as you keep the key pressed.



RD6000

NOTE: Dual-Tone Multi Frequency (DTMF) Signaling by the simultaneous transmission of two tones, one from a group of low frequencies and another from a group of high frequencies. Each group of frequencies consists of four frequencies. Setting Key Beep length to Long will extend the DTMF tone. Press Menu, then press **9_{WXYZ}**, **1_{abc}**, **2_{ABC}** Key Tones using then select Long. Press **OK**.

Volume (Menu **9_{WXYZ}** **1_{abc}** **3_{DEF}**)

1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ}** **Settings**.
3. Press **1_{abc}** **Sounds** and then press **3_{DEF}** **Volume**.
4. Select Ringer / Earpiece / Key Beep.
5. Adjust the volume of the ringer with .
6. Then press **OK** to save the Volume.

Alerts (Menu **9_{WXYZ}** **1_{abc}** **4_{GHF}**)

Any of the three Alert options can be turned on or off.

1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ}** **Settings**.
3. Press **1_{abc}** **Sounds** and then press **4_{GHF}** **Alerts**.
 - Check each option and turn it off if not desired.

RD6000

Service Change (Menu **9_{WXYZ}** **1_{abc}** **4_{GHF}** **1_{abc}**)

Alerts you when service changes. When you enter a service area, the phone displays *Entering Service Area* message. When you leave a service area, the phone displays *Leaving Service Area* message.

Call Connect (Menu **9_{WXYZ}** **1_{abc}** **4_{GHF}** **2_{ABC}**)

Alerts you when the call is connected.

Back To Top (Menu **9_{WXYZ}** **1_{abc}** **4_{GHF}** **3_{DEF}**)


Alerts you when you scroll through the end of a menu list.

4. Select an option and press **OK**.
5. Set On / Off with and then press **OK**.

Power On/Off Tone (Menu **9_{WXYZ}** **1_{abc}** **5_{JKL}**)

Set Power On / Off Tones.

1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ}** **Settings**.
3. Press **1_{abc}** **Sounds** and then press **5_{JKL}** **Power On/Off Tone**.
4. Set On / Off with and then press **OK**.



RD6000

Security (Menu **9_{WXYZ} 2_{ABC})**

Lock Phone (Menu **9_{WXYZ} 2_{ABC} 1_A)**

Keeps your phone from unauthorized use. Once the phone is locked, it is in restricted mode until the lock code is entered. This allows you to receive phone calls and still make emergency calls. The lock code is '0000' by default.

You can modify the lock code using the Change Code within the Security menu.

1. Press Left Soft Key **¶ Menu** and then press **9_{WXYZ} Settings**.

2. Press **2_{ABC} Security**.

3. Enter the four-digit Lock code.

4. Press **1_A Lock Phone**.

5. Select an option and press **OK**.

- **Unlock** means that the phone is never locked (Lock mode can be used). When locked, you can receive incoming calls or make only emergency calls.

- **Lock** means that the phone is always locked.

- **On Power Up** means the phone is locked when it is turned on.

Restrict (Menu **9_{WXYZ} 2_{ABC} 2_{ABC})**

1. Press Left Soft Key **¶ Menu** and then press **9_{WXYZ} Settings**.

2. Press **2_{ABC} Security**.

3. Enter the four-digit Lock code.

4. Press **2_{ABC} Restrict**.

5. Select **On** or **Off** with **OK**.

If you set it to **On** you can only place calls to emergency numbers and phone numbers stored in the phone book. You can still receive calls in the restrict mode.

Emergency Numbers (Menu **9_{WXYZ} 2_{ABC} 3_{DEF})**

You can call emergency numbers even when the phone is locked or restricted. To enter 3 emergency numbers:

1. Press Left Soft Key **¶ Menu** and then press **9_{WXYZ} Settings**.

2. Press **2_{ABC} Security**.


3. Enter the four-digit Lock code.


4. Press **3_{DEF} Emergency Numbers**.

5. Select emergency number using **OK**.

6. Enter an emergency number.

7. Press **OK**.





RD6000

Change Code (Menu **9_{WXYZ} 2_{ABC} 4_{GHI})**

Allows you to enter a new four-digit lock code number.

1. Press Left Soft Key **Menu** and then press **9_{WXYZ} Settings**.
2. Press **2_{ABC} Security**.
3. Enter the four-digit Lock code.
4. Press **4_{GHI} Change Code**.
5. For confirmation, it will ask you to enter the new lock code again.

Erase Contacts (Menu **9_{WXYZ} 2_{ABC} 5_{JKL})**

1. Press Left Soft Key **Menu** and then press **9_{WXYZ} Settings**.
2. Press **2_{ABC} Security**.
3. Enter the four-digit Lock code.
4. Press **5_{JKL} Erase Contacts**.
5. Select Erase all and press **OK**.

Reset Default (Menu **9_{WXYZ} 2_{ABC} 6_{MNO})**

1. Press Left Soft Key **Menu** and then press **9_{WXYZ} Settings**.
2. Press **2_{ABC} Security**.
3. Enter the four-digit Lock code.
4. Press **6_{MNO} Reset Default**.
5. Press **OK**, select Revert and press **OK**.

RD6000

Select Line (Menu **9_{WXYZ} 2_{ABC} 7_{PQRS})**


1. Press Left Soft Key **Menu** and then press **9_{WXYZ} Settings**.
2. Press **2_{ABC} Security**.
3. Enter the four-digit Lock code.
4. Press **7_{PQRS} Select Line**.
5. Select *Line1* or *Line2* and press **OK**.

Call Setup (Menu **9_{WXYZ} 3_{DEF})**

Auto Redial (Menu **9_{WXYZ} 3_{DEF} 1₁₂₃)**

Allows you to set the length of time the phone waits before automatically redialling a number when the attempted call fails.

1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ} Settings**.
3. Press **3_{DEF} Call Setup** and then press **1₁₂₃ Auto Redial**.
4. Select an option and press **OK**.
 - Off / Every 10 seconds / Every 30 seconds / Every 60 seconds.



RD6000

Answer Call (Menu **9_{WXYZ} 3_{DEF} 2_{ABC})**

Allows you to determine when to answer the phone.

1. Press Left Soft Key **Menu**.

2. Press **9_{WXYZ} Settings**.

3. Press **3_{DEF} Call Setup** and then press **2_{ABC} Answer Call**.

4. Select an option and press .

- Flip Open / Any Key / CALL Only

Auto-Answer (Menu **9_{WXYZ} 3_{DEF} 3_{DEF})**

Allows you to select the ring type before the phone automatically answers a call.

1. Press Left Soft Key **Menu**.

2. Press **9_{WXYZ} Settings**.

3. Press **3_{DEF} Call Setup** and then press **3_{DEF} Auto-Answer**.

4. Select an option and press .

- Off

- After 3 secs When you have an incoming call, the phone automatically responds after 3 secs.

- After 9 secs When you have an incoming call, the phone automatically responds after 9 secs.

- Answering Machine The phone automatically responds with the answering machine.

RD6000

One-Touch Dial (Menu **9_{WXYZ} 3_{DEF} 4_{GHI})**

1. Press Left Soft Key **Menu**.

2. Press **9_{WXYZ} Settings**.

3. Press **3_{DEF} Call Setup** and then press **4_{GHI} One-Touch Dial**.

4. Select *Enable* or *Disable* and press .

Voice Privacy (Menu **9_{WXYZ} 3_{DEF} 5_{JKL})**

Set the voice privacy feature for CDMA calls as Enhanced or Standard. CDMA offers inherent voice privacy. Check with your service provider for availability of the enhanced voice privacy mode.

1. Press Left Soft Key **Menu**.

2. Press **9_{WXYZ} Settings**.

3. Press **3_{DEF} Call Setup** and then press **5_{JKL} Voice Privacy**.

4. Select *Enhanced* or *Standard* and press .


Clear Voice (Menu **9_{WXYZ} 3_{DEF} 6_{MNO})**

1. Press Left Soft Key **Menu**.

2. Press **9_{WXYZ} Settings**.

3. Press **3_{DEF} Call Setup** and then press **6_{MNO} Clear Voice**.

4. Select *On* or *Off* and press .



RD6000

RD6000

1x Data (Menu **9WXYZ 4GHI)**

Data/Fax (Menu **9WXYZ 4GHI 1AB)**

In **Data/ Fax** setting, you can use your phone as a wireless modem to avail high speed data services such as browsing Internet and other dial-up networking functions. The wireless phone supports a maximum data rate of 153.6 kbps on the network side. The speed of your connection depends upon network congestion, signal strength, and other variables.

1. Press Left Soft Key **¶ Menu**.
2. Press **9WXYZ Settings**.
3. Press **4GHI 1x Data** and then press **1AB Data/ Fax**.
4. Select an option and press **OK**.
 - Off / Fax In Once / Fax In Always / Data In Once / Data In Always

NOTE: You need to purchase the Data Kit in order to be able to use the phone as modem. The data kit includes a suitable cable that has RS-232 interface for connecting the phone to the PC. Please contact your service provider for further information.

Select Port (Menu **9WXYZ 4GHI 2ABC)**

1. Press Left Soft Key **¶ Menu**.
2. Press **9WXYZ Settings**.
3. Press **4GHI 1x Data** and then press **2ABC Select Port**.
4. Select an option and press **OK**.
 - USB / RS-232C(COM Port) / Closed


Port Speed (Menu **9WXYZ 4GHI 3DEF)**

This setting enables you to set the port speed.

1. Press Left Soft Key **¶ Menu**.
2. Press **9WXYZ Settings**.
3. Press **4GHI 1x Data** and then press **3DEF Port Speed**.
4. Select an option and press **OK**.
 - 19200 / 115200 / 230400

Set the port speed based on your service provider's network. Contact your service provider to determine the maximum available speed.

NOTE: When using the 1X HSPD data service via an RS-232C data cable, the port speed is set to 115,200. (230,400 is not supported). When using the 1X HSPD data service via a USB data cable, you may get better port speed if the port speed is set to 230,400 rather than 115,200.



RD6000

Voice Services (Menu **9_{WXYZ} 5_{JKL}**)

Voice Dial Prompt (Menu **9_{WXYZ} 5_{JKL} 1_{abc}**)

Allows you to set the command for voice dialling.

1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ}** **Settings**.
3. Press **5_{JKL}** **Voice Services** and then press **1_{abc}** **Voice Dial Prompt**.
4. Select an option and press **OK**.
 - Key press / Flip open / Disable

Answering Machine (Menu **9_{WXYZ} 5_{JKL} 2_{ABC}**)


1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ}** **Settings**.
3. Press **5_{JKL}** **Voice Services** and then press **2_{ABC}** **Answering Machine**.
4. Select an option and press **OK**.
 - **Speaker on:** You can hear the other party during the recording of the answering machine.
 - **Speaker off:** You cannot hear the other party during the recording of the answering machine.

RD6000

Train Words (Menu **9_{WXYZ} 5_{JKL} 3_{DEF}**)

Allows you to help your phone distinguish your voice when using voice commands.

1. Press Left Soft Key **Menu**.
2. Press **9_{WXYZ}** **Settings**.
3. Press **5_{JKL}** **Voice Services** and then press **3_{DEF}** **Train Words**.
4. Select Yes or No and press **OK**.
5. If you have selected Yes, you can record Yes according to the message of the phone.
6. Select *Train* or *Un-train* and press **OK**.
7. For voice recognition to be more clear, select Train.
If you chose Train, press **1_{abc}** **OK** and follow the voice prompts.
or
To reset my voice recognition pattern, select Un-train.
If you chose Un-train, press **1_{abc}** **Un-train**.



RD6000

RD6000



5 Safety Guidelines

Phone Info (Menu 9_{WXYZ} 6_{MNO})

S/W Version (Menu 9_{WXYZ} 6_{MNO} 1_{ABC})

Allows you to view the software, PRL, and BREW version.

1. Press Left Soft Key **Menu**.
2. Press 9_{WXYZ} **Settings**.
3. Press 6_{MNO} **Phone Info** and then press 1_{ABC} **S/W Version**.

Icon Glossary (Menu 9_{WXYZ} 6_{MNO} 2_{ABC})

Allows you to view all the icons and their meanings.

1. Press Left Soft Key **Menu**.
2. Press 9_{WXYZ} **Settings**.
3. Press 6_{MNO} **Phone Info** and then press 2_{ABC} **Icon Glossary**.

Shortcut Help (Menu 9_{WXYZ} 6_{MNO} 3_{DEF})

Allows you to view condensed information about using the phone.

1. Press Left Soft Key **Menu**.
 2. Press 9_{WXYZ} **Settings**.
 3. Press 6_{MNO} **Phone Info** and then press 3_{DEF} **Shortcut Help**.
- From the Standby screen, press **CLR**.

TIA Safety Information

The following is the complete TIA Safety Information for Wireless Handheld phones.

Exposure to Radio Frequency Signal

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

- ANSI C95.1 (1992)*
- NCRP Report 86 (1986)
- ICNIRP (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).


The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.



RD6000

Tips on Efficient Operation:

For your phone to operate most efficiently:

Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection

Driving

Check the laws and regulations on the use of wireless telephones in the areas where you drive and always obey them. Also, if using your phone while driving, please observe the following:

- Give full attention to driving -- driving safely is your first responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call if driving conditions or the law so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of 6 in be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

90

RD6000

Persons with pacemakers:

- Should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON;
- Should not carry the phone in a breast pocket
- Should use the ear opposite the pacemaker to minimize the potential for interference
- Should turn the phone OFF immediately if there is any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult the manufacturer.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.


Health Care Facilities

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may use equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

91



RD6000

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Switch OFF your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a "blasting area" or in areas posted: "Turn off two-way radio". Obey all signs and instructions.

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always marked clearly. Potential areas may include: fueling areas (such as gasoline stations); below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

RD6000

FDA Consumer Update




The U.S. Food and Drug Administration's Center for Devices and Radiological Health Consumer Update on Mobile Phones:

1. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the standby mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. What is the FDA's role concerning the safety of wireless phones?

Under the law, the FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a case, the FDA could require the manufacturers of wireless phones to notify

**RD6000**

users of the health hazard and to repair, replace, or recall the phones so that the hazard no longer exists. Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

The FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

The FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. The FCC relies on the FDA and other health agencies for safety questions about wireless phones.

RD6000


The FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term "wireless phone" refers here to handheld wireless phones with built-in antennas, often called "cell", "mobile", or "PCS" phones. These types of wireless phones can expose the user to measurable radiofrequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by FCC safety guidelines that were developed with the advice of the FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have

**RD6000**

yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

5. What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer-promoting effect if one exists. Epidemiological studies


can provide data that is directly applicable to human populations, but 10 or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop — if they do — may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. What is the FDA doing to find out more about the possible health effects of wireless phone RF?

The FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radio frequency energy (RF). The FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The project has also helped develop a series of public information documents on EMF issues.

The FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. The FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts

RD6000

**RD6000**

with independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much radio frequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications Commission (FCC) guidelines that limit radio frequency energy (RF) exposures. The FCC established these guidelines in consultation with the FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless telephones is set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF exposure level for each model of phone to the FCC. The FCC website (<http://www.fcc.gov/oet/rfsafety>) gives directions for locating the FCC identification number on your phone so you can find your phone's RF exposure level in the online listing.

8. What has the FDA done to measure the radio frequency energy coming from wireless phones?


The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the radio frequency energy (RF) exposure from wireless


phones and other wireless handsets with the participation and leadership of FDA scientists and engineers. The standard, "Recommended Practice for Determining the Spatial-Peak Specific Absorption Rate (SAR) in the Human Body Due to Wireless Communications Devices: Experimental Techniques," sets forth the first consistent test methodology for measuring the rate at which RF is deposited in the heads of wireless phone users. The test method uses a tissue-simulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to radio frequency energy from my wireless phone?

If there is a risk from these products — and at this point we do not know that there is — it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radio frequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the



**RD6000**

wireless phone away from your body or use a wireless phone connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radio frequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.


11. What about wireless phone interference with medical equipment?

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, the FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by the FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

The FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a "compatible" phone and a "compatible" hearing aid at the same time. This standard was approved by the IEEE in 2000.

The FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, the FDA will conduct testing to assess the interference and work to resolve the problem.

RD6000



RD6000

12. Where can I find additional information?

For additional information, please refer to the following resources:

FDA web page on wireless phones
(<http://www.fda.gov/cellphones>)

Federal Communications Commission (FCC) RF Safety Program
(<http://www.fcc.gov/oet/rlsafety>)

International Commission on Non-Ionizing Radiation Protection
(<http://www.icnirp.de>)

World Health Organization (WHO) International EMF Project
(<http://www.who.int/emf>)

National Radiological Protection Board (UK)
(<http://www.nrpb.org.uk/>)

RD6000

Consumer Information on SAR

(Specific Absorption Rate)

This Model Phone Meets the Government's Requirements for Exposure to Radio Waves. Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Because the phone is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC for each model.

RD6000

The highest SAR value for this model phone when tested for use at the ear is 1.320 W/kg and when worn on the body, as described in this user guide, is 0.686 W/kg (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID BEJRD6000. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.wow-com.com>.

- * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Service center List

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
1	Andhra Pradesh	Guntur	Vasavi Associates	Door no-6-20-4, Swarnakal complex, 4/1 Akrand Patel, Guntur-22003	MR Satyam	0863-22336718, 98431105789, 08153- 31555554
2	Andhra Pradesh	Hyderabad	Sri Varun Electronics	D.No. 5-3-347/1 " DHAN BHAGYA ESTATE " Ching Ali Lane, Abids, Next to Pashtha Rama Towers, Hyderabad - 500 011	Mr.Raghavendra	040-55253888, 040- 56878822, 040-31001463
3	Andhra Pradesh	Hyderabad	JVR Infotech Pvt Ltd	Shop No. 8, Venjha Vihar Nalgonda Building, Dislukh Nagari Main Road, Hyderabad-500060	EV Ramakanth	04024161848, 040-55109604, 040- 56524157, 040-31151067, 040-38060606
4	Andhra Pradesh	Hyderabad	S V Electronics	Shop No. 11, Nilgiri Block, Adya Endava, Amerpat Main Road, Hyderabad-500038	Mr.Venkateswara Rao	040-55154471/55343030
5	Andhra Pradesh	Kurnool	R K LG CDMA	Shop No 12-A, Andula Khan Estate Beside Yamala Show Room,Kurnool PIN-518002	Mr.G.Rama Krishna	08518-220201, 08518-310688
6	Andhra Pradesh	Nellore	Sir Enterprises	Opp-Anchana Thanthri A.C Centre,Nellore PIN-524001	Mr.Paraveen	0861-3209571, 0861-3100309
7	Andhra Pradesh	Rajamundry	Sri Infotech	Police Welfare Complex,City Hospital Junction,Danvai Pet Maru Road,Rajamundry-531013	Mr.Raghavendra	0883-2421567, 0883-31215799
8	Andhra Pradesh	Secunderabad	Shweta Computers	# 1-7-691 & 1-OPP Adya Devi Hotel,Near Paradesi circle Station Devi Road, Secunderabad - 500003	Mr.Jagdish	040-55334180, 040-31041673
9	Andhra Pradesh	Tripathi	OMT Computer Services	18-42/2 VI / Metal Road,OPP HDFC BANK, Tirupati PIN-517501	Mr.K.vesu Naidu	0877-5561979, 0877-3120209
10	Andhra Pradesh	Vijaywada	K.L.Computer House	33-9-46 SVS Temple Street,Labipet,Vijaywada PIN- 520 010	Mr.Kartik	0866-5520461/ 5677491, 0866- 3105222
11	Andhra Pradesh	Visakhapatnam	S V Electronics	D No 303-111,Daba Garden, Main Road, Visakhapatnam PIN-530020	Mr.Nani	0891-2598610, 0891-276074, 0891- 3706074
12	Andhra Pradesh	Warangal	S S Manievers am	6-1-707/1 Sri Bhavan, Sri Sri Theatre Road, Warangal-506001	Mr.L. Srinivas Rao	0870-2552223, 0870-310708
13	Bihar	Jamshedpur	Pasad Electronics	Shop No. 23, Ground Floor, Yash Kamal Complex, Bistupur, Jamshedpur - 831010	Ranji Kumar Prasad	0687-2487280, 98355164605
14	Bihar	Patna	Infinet Traling Company	1st floor, City Palace New Dak Bunglow Road, Patna- 800001	Sanjay Chowdhury	0612-2227166
15	Bihar	Ranchi	Sanya Systems & Solutions	153, Opp Hotel Palace, Kadru, Ranchi-834002	Amit Rastogi	0651-2341361, 9835167667

RD6000

Sr	Circle	City	ASCS's Name	Address	Contact Person	Phone
16	Delhi	Delhi	Conhardt Systems	C-1/A Aurora Park, Laxmi Nagar/M S Chamber, Milan Vihar Marg, Delhi-110027	Mr Ravi Kant Gupta	011-22553144, 1136783600, 011-30955987
17	Delhi	Delhi	Innovative Telecom	305, Agarwal Millennium Tower, Netaji Subhash Place, Pitam Puri, Delhi-110088	Mr Manoj Garg	011-55154343, 9811682453, 11309255753
18	Delhi	Delhi	Sagar Technologies	21/F, F/Floor/West Patel Nagar, Opp Vivek Cinema, Delhi-110028	Mr Deepak/Mr Amit	9811288618/0223, 9811032017/98118341977
19	Delhi	Delhi	Sagar Technologies	J-39, Central Mkt., Lajpat Nagar-I, New Delhi-110224	Mr Prabhat	011-29831108, 98110542287
20	Delhi	Delhi	Ucom Technologies Pvt.Ltd.	45, 1st Flr, Corner Mkt., Matiya Nagar, New Delhi - 110017	Shielendra Verma	011-26675900/56655382, 98102974244, 9810341374,
21	Delhi	Delhi	Nice Telecommunication	152/3, DDA Complex, Nangri raya, Delhi - 110046	Umang Premi	011-28521044, 9810341374, 98110138894
22	Delhi	Delhi	Touch Tone Telecom	B-52, First Floor Kalyan, New Delhi	Ashish Day	113093031
23	Gujarat	Ahmedabad	Visual Enterprises	104, Saatnath Complex, behind Ujja House, Swastik Cha Rasta, Narangpura, Ahmedabad-380009	Mirza Patel	079-6438609, 31037582
24	Gujarat	Ahmedabad	Silicon Valley	F/6, Silver lake, Jagatpura Park, RamBaug Road, Maninagar/Ahmedabad-380008	Rajesh Patel	079-543634, 9824205430, 38163945
25	Gujarat	Bhavnagar	Teletext Gold	G-8, Redhestian Complex, Radha Mandir/Vaghavadi Road, Bhavnagar-360001	Nilesh Bagadia	02762415645, 9825206498
26	Gujarat	Gandhinagar	Creative Communications	F-11, Megimalaiya Complex, Ch/Road Sector-11, Gandhinagar	K.J.Borot	079-3226241, 9824003132, 31005586
27	Gujarat	Jamnagar	Sudarsan Infosys	1 K.D.Complex/Nr Shrinath Travel Agency/India Mandir, Sudarsan Chowk/Chamrajnagar-361001	Amit Unakat	0288-2552996, 9824476203
28	Gujarat	Rajkot	Roopang info-care	Vinod Nivas/A, Sardarwala (West), Nr. Aston Cinema, Rajkot-360001	Kalpesh Rupani	0284-2464495, 9824066880, 31006222
29	Gujarat	Surat	Excel Solutions	G-48, Aiston Plaza, Aminor Mahal Road, Adajan Surat-395009	Nilesh Ghosal	0261-5544800, 98880138480
30	Gujarat	Vadodara	Aashnik Infotech	F/50 National Plaza/R.C.Dutt Road/Arikapuri/Vadodara-390005	Aashish Parmar	0265-232316/3099693/3112123

Sr	Circle	City	ASCS's Name	Address	Contact Person	Phone
31	Haryana	Amritsar	Bee Ess Air Communication	92-93, Gandhi market, Amrit Cantt-133001	Rajiv Gupta	0171-2641234, 9416021234
32	Haryana	Faridabad	Hi-Tech Communication	105, Sector 10, Faridabad-121006	Rahul Jindal	0129-2223422, 9811046663
33	Haryana	Gurgaon	Avon Technologies & Telecommunication	729, A, 1st floor, Mehrauli Road opp. ITI, Near Kalbani hospital, Gurgaon-7-122001	G D Bhargava	0124-2220289, 124-3564294
34	Haryana	Karnal	Mass Communication	7, Daya Singh Colony, Kunjputra Road, Karnal-320001	Ms Priki	0184-3090177, 98883535205
35	Haryana	Panipat	INS Telecom	No. 1, West Printing Market, Near Hotel West G T Road, Panipat-132103	Jagdeep Sachdeva	0180-50056360/59, 9812072860
36	Haryana	Rohak	Telecentre	Shakti Market, Civil Hospital Road, Near Chhotu Ram Chhatri, Rohatka-124001	Mr.Madaan	01262-247422, 988962493922
37	Haryana	Sonipat	Telaword	21, W C Thakur Subhash Chowk, Sonipat-131001	Vipin Dua	0130-2255955, 9812044888
38	Karnataka	Bangalore	Meenakshi Electronics	#128, Lalbagh Main Road, Bangalore-560027	Mr. Ramesh.	080-56992943/309617345, 8031810375
39	Karnataka	Bangalore	Optima Mobile Services	591-B, Dr Rajkumar road, 2nd block, Rajaiv Nagar/Bengaluru-560010	Ummi Krishnan	080-3131953, 8031866656
40	Karnataka	Bangalore	Optima Mobile Services	B-3, Maligajpura Complex, Opp R. Nagar Police Station, 80-Foot Road, R. Nagar, Bangalore-560032	Prasad	080-30610202
41	Karnataka	Bangalore	Paranav Infocom	block 12, Banashankari Bangalore-560011	S.V.Srirish	080-56697937, 080-31860269
42	Karnataka	Bangalore	Paranav Infocom	267/1, 1st Main Road 6th Cross, Behind Shanti Nagar Domlur Layout, Bangalore-560077	S.V.Srirish	80-56969937, 90-31810269
43	Karnataka	Belgaum	HeLo India Telecom	G-4, Maratha Mandir Complex, Kharapur Road, Near Railway Flyover, Belgaum-580001	Sanjay	9843272753/10831-3101800
44	Karnataka	HUBLI	Naveen Communication	#19/20, 2nd floor, Eureka Junction, Travellers Bunglow, Road Hubli-580 023,	Naiveenraju S V	0836-2355302, 0836-340376
45	Karnataka	Mangalore	City Talk Communication	GULF PLAZA, G-5, Near KSRIC Bus stand, Beljai, Mangalore-575001	A V Prabhu	0824-3344528, 0824-817528

Sr	Circle	City	ASCS Name	Address	Contact Person	Phone
46	Karnataka	Mysore	K K Marketing	14/209 Tribhuvan Towers, Opp Veterinary Hospital -570001 Dewan's Road, Dhanwantri Road Cross, Mysore -570001	Mr. Karunakaran.	0821 3120789
47	Kerala	Ernakulam	Zenicon	2nd Floor, Therien's Building, opp Ship Yard, M.G. Road, Ernakulam-682015	Jaimon Joseph	0484-2371511 9846127788
48	Kerala	Irrinjalakkuda	Albar Mobiles	376-44, Near St. Joseph's college junction, Irrinjalakkuda-680121	Mr Sebastian	0480-830796
49	Kerala	Kaunagappa IV	Supreme Enterprises	Opp to KSRTC Bus stand, Kaunagappa-680318	Mr. Raith	0476-2520282
50	Kerala	Kollam	Digital Ixsystems	MC-3087, New Block, Bishop Jerome Nagar, Chinnakada, Kolom-691101	Johnson Lawrence	0474-2760647 9846007059
51	Kerala	Kottayam	SWI Technologies	NSS Building, Near Pallippurathikku Temple, Kodumparamba, Kottayam - 683002	Rajesh K S	0481-2565303 9847310123
52	Kerala	Kozhikode	Domain Irisystems	Domain Irisystems, 2nd Floor, Darussalam Complex, Makor Road, Kozhikode - 673104	Mukundan	0485-2722222
53	Kerala	Manjeri	Albar Mobiles	16-870-A, Ody Road, Manjeri-673121	Mr Harry	0483-2765835
54	Kerala	Marvelikkara	Ettirattaryl Agency	Ettirattaryl complex, K P Road, Kayankulam-691502	Anu T cherian	0479-2447601 0479-3100025
55	Kerala	Palakkad	Albar Mobiles	N.S. Towers, Kalamandalam junction, Palakkad - 678001	Suresh	0491-2523829 9847086446
56	Kerala	Thiruvananthapuram	Supreme Systems	TC 202302, Kadaleparam, Karanana P.O., Thiruvananthapuram - 695 002.	Santosh	0471-2340523
57	Kerala	Tirur	Albar Mobiles	72-Ancila Building, Ferizhalabam, Tirur - 676101	Mr Biju	0494-2427444
58	Kerala	Tiruchir	Albar Mobiles	Kadaiyathodi Building, North Bus stand, Tiruchir - 630 001	Sojan	0487-2323424
59	Madhya Pradesh	Bhopal	Neha Sales Corporation	F-04, Amda Tower, E-5/4, Commercial Zone, Area Colony, Bhopal-462016	Ashok Hirwani	0755-5277247/22420988, 9826072327
60	Madhya Pradesh	Gwalior	Computer Clinic	Global Apartments, City Centre, Opp Income Tax Office, Gwalior.	Rishi Sharma	0751-2233088

RD6000

Sr	Circle	City	ASCS Name	Address	Contact Person	Phone
61	Madhya Pradesh	Indore	Neha Sales Corporation	M-3, Mezzanine Floor, Akash Deep Shopping Complex, Neha Nagar, Sector 8, Sangeeta Road, INDORE - 452001 (M.P)	Ashok Hirwani	0731-5091833 98260772327
62	Madhya Pradesh	Jabalpur	S M Shree	846, Chatrapuri Bhawan, Nr Ashoka Hotel, Wright Road No. 1, VIKAS JAL	0761-5065183	
63	Madhya Pradesh	Raipur	Cybernet Systems	B-2, 1st Floor, Geetach Complex, Jai Road, Raipur - 492001	Anand Singh	0771-2524033 9826132918
64	Maharashtra Amravati		Scopio Services	Shop No. B4, Ground Flor, Gulshan Towers, Nr. Panchsheela Cinema, Amravati, Pin-446601	Lakhan	0721-2567302, 0721 3151826,
65	Maharashtra Aurangabad		Unique Telematics	Shop no. 10/B, Behind Sapawai Handloom, Tapolya Super Market, Nizala Bazar, Aurangabad-431001	Nivedita	0240-2356447 9823007730, 0240-3110364
66	Maharashtra Chinchwad (Pimpri)		Ritz Communication Services	Shop No. 22, Gawde Kunal Garden, Pimpri-Chinchwad Link Road, Chinchwad, Pune-411033	Mr Reiaz	020-2455613, 9822275766, 020-31029777
67	Maharashtra Kolhapur		SS Services	S.S. Divyan Tower, Opp. Nuran Marathi School, Near Mitali Kanki, Kolhapur, Pin - 416005.	Prakash Patil	0231-2541120 9823026120
68	Maharashtra Margao		Comkine Surengs India Pvt Limited	Ground Flor, Shop No. 10, Garden view building, Near to UTI Bank, Near Margao Municipal Garden Margao-403601	Sunil	0832-3105629, 9822101522, 0832-3105637
69	Maharashtra Nagpur		Spectrum Marketing Services	Shop No. C, Dharampuri towers, West High Court (WHC) Road, Dharampuri, Nagpur - 441001	Sonali	071-25227823, 9823338333,
70	Maharashtra Nasik		Elcomp Services	Bs Nidhi Park, Pakwadi, M.G Road, Nasik, Pin-442001	Rajesh Laxmikant	071-3095700, 071-81866
71	Maharashtra Panjim		Comlink Synergies Pvt Ltd	Ground Flor, Goemex Building, Cetano De Almeida Road, Panjim-403001	Joshi Sunil	023-2426978, 9822101522, 0832-3105629
72	Maharashtra Pune		Digital Concepts	Shop No. 5, India Complex, Besides Kaka Haval, LBS	A Ahmed	020-4012821, 9822438818, 020-31029798
73	Maharashtra Sangli		Ramesh Electronics	Opp. Kanya Puishi prashala, Parwada, Sangli-416416	Suresh Shegane	0233-227601, 9823085176, 0233-3107601
74	Maharashtra Solapur		Javahe Radio Services	184, Gold Finch Petli nr Hotel Ritesh, Solapur - 413007.	Prassanna J Chavan	021-2725030, 9422458830
75	Mumbai	Kalyan	Vish Technologies Pvt Ltd	SHOP-14, GROUND FLR, ARCHIES APARTMENTOK BAUGA KALYAN-42301	Pawan	022-3297555

RD6000

RD6000

Sr	Circle	City	ASCS Name	Address	Contact Person	Phone
76	Mumbai	Vasai	E-Link Solutions	Shop No.5, Type C, Bldg. no.56, Shanti Vihar, Mitra Road	Kamlesh	022-28852087, 9821734223
77	Mumbai	Mumbai	Ron Technologies Pvt Ltd	12 Pawana Street, Bajaram mohan Box Road Pali	Vishwas	022-23964166, 9820098916/022
78	Mumbai	Mumbai	MR Telecom	Puris Building, Grant Road East, Mumbai - 400004	Shrawlesh	33864166 022-25285561, 9820137910/022
79	Mumbai	Mumbai	Everest International Pvt Ltd	Shop No. 2, Anar Kun Building, Pastar Sugar Roar no.2, Amravati, Lant Opp Shopper Stop, Chembur, Mumbai - 400068	Cheetan	022-28875522, 9821048111
80	Mumbai	Mumbai	LG Service Center	45, Udyog bhavan, Sonwala Road, Goregaon east, Mumbai - 400063	Rajib Saha	022-24947375
81	Mumbai	Navi Mumbai	LG Service Centre DAFC	Shop No.5, Lower Part, Mumbai-400013	Rainish	022-30388052, 022-33480405
82	Mumbai	Thane	Viraj Technologies Pvt Ltd	A Block, Ground-floor, Dhruvam Ambani Knowledge City, New Mumbai-400709	Vinod Jakolya	022-25304960, 9821068231,
83	Mumbai	Navi Mumbai	Hello World	Shop no.3, Mira Chhaya Axt, Municipal Corporation Road, Panj Pakhadi, Thane (W) - 400601	Manesh	022-27657705, 022-32741396
84	Odisha	Bhubaneswar	SAINFOSTS	Shop No.33, GF, Vedere Chambers, Sector-17, East Bhubaneswar-460075	Sarabjeet Singh	0674-25731314
85	Odissa	Cuttack	OAINFO TECH	291,Bamhia, Opp.Akshaya drama hall, Bhubaneswar-751010	Manas	0671-2312613
86	Punjab	Amritsar	Bajaj Telecommunication	Behind Govt Bus Stand, Badamia, Cuttack-751012	Mahapatro	0163-5096511, 9417040014
87	Punjab	Barnala	Lalli's Electronic Gallery	87, G Floor Nehru Complex, Lawrence Road, Amritsar-143001	Suman Bajaj	01679-238007, 9815075670
88	Punjab	Bathinda	Lalli's Electronic Gallery	Kartar Nagar,Mitali Street, Bathinda-148101	Pankaj Goyal	0164-2239500/2236337,
89	Punjab	Chandigarh	Global Systems	1138A, First Floor, Amrik Singh Road, Nr Gole Diggji, Brahma-161005	Ashok Kakria	9814222310
90	Punjab	Hoshiarpur	Kulip's Mobile Care	SCO-302/22, First Floor, Sector-22-D, Chandigarh-160022	Sulalit Gupta	0172-3888333, 3814002284
				Dhobial/Vill Gali/Pitagarwa Road, Hoshiarpur-146001	Kulip	01882-228906, 9815073906

Sr	Circle	City	ASCS Name	Address	Contact Person	Phone
91	Punjab	Jalandhar	Mobile Center	Shop No. 5, Hotel Preet Market,Naodher Road,Jalandhar-144001	Jogesh Diwan	0181-5073344, 9814029696
92	Punjab	Ludhiana	Rahul Telecom	Shop No. 3 Skand Tower, Dr Hieera Singh Road,Gowal	Ani Kumar	0161-2413884, 9814651803
93	Punjab	Mohali/Kota	Image Services	Opp. Manigiri Govt College, ModelKotla-148023	Rohit Bansal/Raj Verma	01675-253899, 9814040066, 01675-331979
94	Punjab	Moga	Super Communication	Pawan Market,Opp shankar Batteries,Court Road, Moga-142001	Jai Deep Mehta	01636-227440
95	Punjab	Patiala	Image Services	84,First Floor, Leela Bhawan, Patiala-147001	Rohit Bansal	0175-22227936, 9814040066
96	Rajasthan	Jaipur	Kamashishi Telecom	1st Floor, Sunny house, (C2) Malviya Nagar, C Scheme, Near government press, Jaipur-302001	Rahul Bhargav	0141-507280, 98229012478, 0141-312863
97	Rajasthan	Jodhpur	Omega Electronics	UGA, Adishwar Tower, Main Chapsani Road, Opp. Gehir's Watch Co., Jodhpur-342003	Pratap Singh	3091219, 0291-3117171
98	Rajasthan	Kota	Cyber Infsystems	26, Ground floor, Kalawati, Pawali market, Gumanpura, Kota-324007	Shyam Maheshwari	0744-2320153, 98292321847
99	Rajasthan	Udaipur	Ficus Enterprises	13,Darsangpur Opp.M.B.Commerce College Gate/N Computer Zone,Udaipur-313002	Virendra Ranika	0294-2410002, 241303/2, 3410002
100	Tamilnadu	Chennai	Unicare Incomm Services	73, Nived Plaza, Shop no G-3, G Floor, Aricot Road, Kodambakkam, Chennai - 600010	Rakesh/Karlik	044-24724666, 9841036466
101	Tamilnadu	Chennai	GS Systems	547,652, 6/F Towers, Mount Road, Nandiyaram, Chennai-600035	Mrs N S Vijayi	044-24330889, 9884165010
102	Tamilnadu	Chennai	UCom Technologies Pvt.Ltd	Shop No.2, Old No.24, New No.30, Balfour Apartments, Kupak, Chennai-600010	Shyam	044-22717466/52175115, 9884178700
103	Tamilnadu	Chennai	Escom Systems	Aurodya Complex, New No.5/7, Old No.26/7, Ponnammai High Road, Chennai-600003	Mrs N S Vijayi	044-30901688
104	Tamilnadu	Coimbatore	Fast Track	Sudera Complex, 35A-B, 100' Feet Road, COMBATOR-E - 641012	Anand Prakash	0422-2490577, 9843060040, 0422-310080
105	Tamilnadu	Cuddalore	Kasturi Cellular Service	# 2, Una Complex, Ustaisi,Riverside Road,Opp Tharakatha Kalaimamangalam,Koil,Puliappan,Cuddalore-607001	Mr Raghupati	04142-220183

RD6000

Sr	Circle	City	ASC's Name	Address	Contact Person	Phone
106	Tamilnadu	Erode	JANS Electronics	148, Natru Road, Opposite shaktivinayak temple,Dera Complex, Erode-638011	M Kanan	0424-2258526 9442263508
107	Tamilnadu	Madurai	Deeva Electronics	No.4, Thimirkulam North Street, Near Ayappan Koil, Thalakkulam, Madura-625002	Guna	0452-2228179/3107985
108	Tamilnadu	Pondicherry	Digital Logistics	126/2, Peermakalai Street (Bharathi Street Cutting), Pondicherry-605001	G Singaravelu	0413-2222148, 9843093348, 0413-3155351
109	Tamilnadu	Salem	Global Care	262-A, Adithya Astham Road Salem - 636004	Vasudev Nayak	0427-2337877, 0427-3102124, 0427-3102124
110	Tamilnadu	Tiranjavur	ZM Electronics	33, New Thamirabur Shopping Complex, Opp UGC Gandhi jி road Thanjavur-613001	Ziauddin	04362-272595, 04362-313254
111	Tamilnadu	Tirunelveli	Classic Electronic	38, Tirunelveli Road, Opposite Kalmark, Welcome Complex, Peeyankottai, Trivandrum-627002	Erkins	0462-2575801
112	Tamilnadu	Tirupur	Sini Vasavi Electronics	#185-303, Mangalam Road,Karuvam payam, Tirupur -641604	MR.U.B. Bala	0421-2243005, 98422-74300, 0421-3105560
113	Tamilnadu	Tirchy	S K Electronics	2nd Floor, Siva Complex, Bishop Road, Puthur, Trichy-620017	Krishnan	0431-2742646, 9843178104, 0431-3101502
114	Tamilnadu	Vellore	Kelon Engineers	68A, Officers Line, Tel Gate, Vellore - 632001	MR.V.S.Kumaran	0462-2214396, 9843007761
115	Uttar pradesh	Agra	NSC Computers	Stop No G-124, Block No- 28, Sanjay Place, Agra -282002	Rajiv Singh	0562-2820032, 562-3111350
116	Uttar pradesh	Aligarh	A.V Computer Services	G-1, Ganpati Plaza, Jha Compound, Marris Rd, Aligarth-202001	Vaibhav	0571-2506148, 9412274391
117	Uttar pradesh	Allahabad	B.P.Electronics	G-11, India Bhawan, Ground Floor, Civil Lines, Allahabad-211001	Ms.Naina Pandey	0532-2608088
118	Uttar pradesh	Bareilly	Sapan Infotech	106/17 1st Flor,Civil Lines,Opp Bankik Petrol Pump,Bareilly,Pin 243001	Sanjeev Singh	0581-2477552, 9897209564
119	Uttar pradesh	Dehradun	Krishna Communication	Shop No 15a, Meetha Plaza, Rupri Road, Dehradun Uttrakhand-248010	Vinod	135 3090895, 135 3112922/135 3119866
120	Uttar pradesh	Ghaziabad	S P Telecom	G-2, Konak Building, Raj Nagar District Centre (RDC), Rajnagar, Ghaziabad	Mr Aagrahari	0120-2706340, 32980893, 3421669

RD6000

Sr	Circle	City	ASC's Name	Address	Contact Person	Phone
121	Uttar pradesh	Gorakhpur	Eternal Electronics	Shop No.11, Pandey Complex, 33, Kasya Road, Opp DIG Building, Gorakhpur-273002	Ram Praap	0551-2204520
122	Uttar pradesh	Kanpur	AR Infotech	111/87 Ashok Nagar,Kanpur Pin 208012	Manoj Shukla	0512-3111662, 9833068734, 0512-3033011
123	Uttar pradesh	Lucknow	NETCOM	3 way road, City Point, Opp Krishi Bhawan, Lucknow-226024	Kawalejet	0522-3094222
124	Uttar pradesh	Meerut	Systech Computers	F-14/25, 1st floor,Ganga Plaza, Begum Bridge Road, Meerut-250002	Vineet Goyal	0121-2691167, 121 3116631
125	Uttar pradesh	Muzaffarnag ar	Jai Computer Services	Shop No.4, 1st Floor, Roonkee Dad, Near Shiv Chouk Central Park,Muzaffarnagar-251001	Manohar Singh	0131-2635483, 9412110215
126	Uttar pradesh	Noida	M.R Telecom	J-45, First Floor Sector-18, Noida-201301	Kalash Aggarwal	0120-2591440, 9816022866
127	Uttar pradesh	Saharanpur	Maharaj Communications	Near Matargya Palace,Delhi Road, Saharanpur-247001	Pankaj Malhotra	0132-2720881, 132 3111202
128	Uttar pradesh	Varanasi	Shiam Mobile Distributors	Shop No.5,B37/115-B-1 Baradari Complex,Rathyatra Crossing,Varansi Pin 221010	Rishi Mohan	0542-2363296, 98339241004
129	W Bengal	Asansol	Sky Computer & Telecom	Islam Market, Nundmon Road, Asansol-713301	Syed Arshad Ali	0341-2207719, 9832176886
130	W Bengal	Burdwan	San Infosys	Tikona Bus Stand Central Mkt, GTI Road, Burdwan-713101	Sanjit Debnath	0342-3090265, 9833219270
131	W Bengal	Calcutta	Bennam Infosol Pvt Ltd.	344 Corat Street, Shibpur, Kolkata - 700048	Arun Surana	033-254437779, 98331077143
132	W Bengal	Calcutta	J.P.Computers	5B Ekdala Place, Kolkata - 700019	Sonim Kabir	033-24401923
133	W Bengal	Calcutta	Skylink	81/A Little Russel Street, Calcutta-700071	H R Molia	033-30903814, 033-32091037
134	W Bengal	Durgapur	Tech International	Red Cross Road, City Centre, Durgapur-713216	Amitava Banerjee	0343-2546893, 9434002244

RD6000